


ShipModul

Marine Electronics

MiniPlex-2 series NMEA 0183 multiplexer Manual



This manual covers:

MiniPlex-2S

MiniPlex-2S/BT

MiniPlex-2USB

MiniPlex-2USB/BT

MiniPlex-2E

MiniPlex-2Wi

MiniPlex-2 series, V2.0
Firmware V3.20.x
Rev. A, 19-2-2013

© ShipModul B.V, 2025

Introduction	4
NMEA 0183	4
NMEA Sentences	4
Talkers and Listeners	4
The Multiplexer	5
The Host	5
The MiniPlex-2 Multiplexer	6
Galvanic Isolation	6
Outputs	6
Feature Set	6
Host Port	7
RS-232 Serial Port	8
USB Port	9
Driver Installation	9
Bluetooth Interface	14
Network Interface	15
Network Basics	15
IP Address	15
Netmask	15
Port Number	15
Protocols	16
Assigning IP addresses	16
MiniPlex-2E Network Setup	17
Search	18
Network Recovery	19
WiFi Interface	20
WiFi Access Point	20
NMEA Ports	22
NMEA Signals	22
NMEA Inputs	22
NMEA Outputs	23
Warning	23
Combining Ports	24
SeaTalk	24
Power Supply	25
Indicators	25
Data Throughput	26
MPX-Config	28
Menu	29
Controls	30
MiniPlex Connection	30
Viewer Options	31
NMEA Inputs/Outputs	31
Options	35
NMEA Conversions	36
Sentence Filtering & Routing	37
Firmware Update	40
WiFi Firmware Update	40
Preparation	41
Windows Firewall	41
Procedure	41
Mounting	42
Technical Reference	43
NMEA Glossary	43
Talker ID's	43
Sentence formatters	43
Translated SeaTalk datagrams	45
Firmware Update Error messages	46
WiFi Update Messages	47
Proprietary NMEA Sentences	48
Example	48
\$PSMDCF – Set Configuration	48
\$PSMDDR – Set Default Route	49
\$PSMDFL – Set Filter Rules	49
\$PSMDID – Set Talker ID	50
\$PSMDIN – Input options	50

\$PSMDLDR – Loader message	51
\$PSMDOP – Set Options	51
\$PSMDOV – Overflow	52
\$PSMDRESET – Reset the multiplexer	52
\$PSMDSP – Set Speed	53
\$PSMDUI – Set Unique Identifier	53
\$PSMDVER – Get Version	53
\$PSMDWI – Wireless control	54
Channel Information.....	56
STN – Multiple Data ID.....	56
TAG Blocks	56
Technical Specifications	57
MiniPlex-2S	57
MiniPlex-2USB	57
MiniPlex-2S/BT	58
MiniPlex-2USB/BT.....	58
MiniPlex-2E	59
MiniPlex-2Wi.....	59

Introduction

The MiniPlex-2 series NMEA multiplexers enable the connection of multiple NMEA 0183 devices and a host device like a PC, a laptop or a tablet. All models share the same number of NMEA ports and features. They differ in the type of host interface, the interface that talks to the computer.

This manual covers all models of the MiniPlex-2 series. There is a chapter for each type of host port. The remaining part of the manual covers NMEA connections and configuration, which are the same for all models.

We will also explain NMEA 0183 and how things connect (or not).

NMEA 0183

The NMEA 0183 Standard, a communication standard defined by the NMEA organization (www.nmea.org), defines a communication protocol called NMEA 0183 that enables navigation instruments and devices to exchange data with each other.

This way, a compass can send a heading to a radar to enable a north-up display, a GPS can send cross-track and waypoint information to an autopilot in order to steer a programmed course.

NMEA Sentences

NMEA data is made up of readable text sentences. If you would connect the output of a navigation instrument to the serial port of a computer and start a program that displays the incoming data, you would see something like this:

```
$GPGGA,143357.999,5301.0061,N,00635.5479,E,1,06,1.9,90.0,M,,,,0000*2E
$GPGGA,143357.999,5301.0061,N,00635.5479,E,1,06,1.9,90.0,M,,,,0000*39
$GPGLL,5301.0061,N,00635.5479,E,143357.999,A*22
$HEHDT,67.0,T*1E
```

This is plain text in a format that is laid out in the NMEA 0183 standard. Every device that receives this information would know that the sentence starting with GPGLL originates from a GPS (hence the GP at the beginning of the sentence) and that it contains the geographic longitude and latitude (GLL).

The term "NMEA sentence" is used for NMEA data because it is made up of single lines of text. Throughout this manual, "NMEA sentences" and "NMEA data" will be used randomly.

Talkers and Listeners

The NMEA 0183 standard defines talkers and listeners. A device that sends information is a talker and a device that receives information is a listener. When connected to each other, the talker sends information to the listener.

Communication using the NMEA 0183 protocol involves at least one talker sending data to one listener. Figure 1 on the right shows such a minimal system: a gyrocompass sends heading data to a radar.




Figure 1

It is important to know that a talker or listener port is named after its function, not after what it is connected to. So a talker port sends out information but it connects to a listener. This might be confusing at times so further in this manual we will use the terms input and output instead of listener and talker port respectively.

The NMEA 0183 standard specifies that a talker should have enough driving capacity to talk to four listeners. This is as easy to achieve as telling a story to an audience of four people - the only requirement is to talk loud enough.




Figure 2

The left part of Figure 2 shows such a situation: one GPS sends data to four devices.

It gets complicated when several talkers must send data to one listener (the PC) as shown in the right part of Figure 2. Unless that listener has multiple inputs, this is not possible without help.

Simply connecting multiple talkers to one listener as shown is like four people simultaneously telling you a different story. You can make neither head nor tail of it. In electronics terms: the outputs of the talkers will short-circuit each other and the sentences they transmit will be corrupted.

This is where a multiplexer offers the solution.

The Multiplexer

A multiplexer, sometimes called combiner, has multiple listener ports, each acting as a listener connected to a single talker. It also has at least one talker port that outputs the combined data from the inputs to a listener. So what seemed impossible in Figure 2 is possible when a multiplexer is added as shown in Figure 3. The multiplexer listens to the instruments by storing the received NMEA sentences into queues simultaneously. At the same time it retrieves the sentences from the queues sequentially and sends them to the PC.

Since a PC can do so much more than just displaying the combined data, it soon became apparent that a multiplexer needs more than just a few inputs and one output. The single talker port that connects to the PC became a host port, being input and output at the same time. A few extra talker ports made it possible to send data to other devices and to drive an autopilot.




Figure 3

The Host

NMEA 0183 devices already existed before it was common practice to use a computer for navigation. Of course there were ECDIS systems (Electronic Charting and DISplay) but these were used only on commercial ships. Nowadays it is very common to use a computer, a laptop or a tablet as a charting device while the navigation software sends information to an autopilot in order to automatically follow a programmed route. The PC becomes a host and what used to be a talker port on the multiplexer is now called a host port. The multiplexer becomes the central interface that listens and talks to all navigation instruments and devices.

Throughout this manual, the common term host is used for a PC, laptop, smartphone, PDA, tablet or any device that is connected to the multiplexer to receive the combined NMEA data for processing and display.

The host interface or host port is the interface that connects to these devices and this can be an RS-232, USB, Ethernet, WiFi or Bluetooth interface.

The MiniPlex-2 Multiplexer

The MiniPlex-2 multiplexer is an advanced NMEA 0183 multiplexer with four NMEA inputs or listener ports, two NMEA outputs or talker ports and one or two host interfaces.

It combines NMEA sentences that are received on the NMEA inputs and it can send these sentences to the NMEA outputs and to the host interface(s). These host interfaces can also be used to send NMEA sentences back to the multiplexer to be forwarded to its NMEA outputs and to send commands to configure the multiplexer.

Figure 4 shows a typical setup where the MiniPlex-2 is used to combine data from four instruments, send it to a PC and, depending on the configuration of the MiniPlex, send the same data to an autopilot and a repeater display. The PC is also capable of controlling the autopilot to steer a programmed route and to display information such as distance to next waypoint on the repeater display.




Figure 4

Galvanic Isolation

Every NMEA input of the MiniPlex-2 is galvanically isolated, sometimes called opto-isolation because opto-couplers are used to achieve this isolation. An opto-coupler is an electronic component that transports information by means of light instead of electricity, thus creating a barrier for electrical currents and voltages.

A galvanically isolated input prevents unwanted flow of electrical currents between instruments and the multiplexer. These currents could damage the instruments or interfere with radio signals and should therefore be avoided. Galvanically isolated inputs are required by the NMEA 0183 standard.

The host port or interface of the MiniPlex is also galvanically isolated in order to isolate the host from the navigation network and protect it against potential damage caused by ground loops or voltage spikes.

Outputs

Both NMEA outputs can drive up to four listeners each. Flexible routing options allow you to specify which NMEA sentences are sent to these outputs. The outputs are not galvanically isolated. The NMEA 0183 standard does not require this. It isn't necessary either, because each connected input is galvanically isolated.

Feature Set

Besides the basic functionality of combining NMEA sentences from multiple sources, the MiniPlex-2 offers a range of features like sentence filtering and routing, input priority with automatic switchover, testing of data integrity, NMEA conversions, Talker ID modification and SeaTalk® to NMEA translation.

The MiniPlex-2 can be integrated seamlessly into an existing Raymarine SeaTalk network when SeaTalk mode is enabled. This mode changes one NMEA input into a SeaTalk input. When connected to a Raymarine SeaTalk network, the multiplexer translates SeaTalk data into NMEA sentences and combines these with NMEA sentences that are received on the other inputs. Only one SeaTalk input is needed since the SeaTalk bus connects all instruments together through one single cable.

SeaTalk to NMEA translation in the MiniPlex works one-way only: no NMEA sentences are converted into SeaTalk, the multiplexer just listens on the SeaTalk bus.

All MiniPlex-2 models have the same features and number of NMEA inputs and outputs. The only difference between each model is the type of host port. The following chapters describe the details of each host port.

Host Port

The host port is the port that connects to a PC, laptop, smartphone, PDA, tablet or any device that is connected to the multiplexer to receive the combined NMEA data for processing and display. The type of host port differs for each type of multiplexer and some multiplexers have two host ports.

The host port is always bi-directional: it delivers the combined NMEA data from the NMEA inputs to the host and it also receives NMEA data from the host to be sent to the NMEA outputs of the multiplexer. The host port is also used to configure the multiplexer and to update its firmware.

There are two types of host ports: wired ports like RS-232, USB and Ethernet and wireless interfaces like WiFi and Bluetooth. Both types work equally, have equal priority and can be used simultaneously.

The only restriction of the wireless interfaces is that they cannot be used to update the firmware of the MiniPlex. See chapter "Firmware Update" for more details.

The following chapters describe each type of host port. The applicable type of multiplexer is listed underneath the caption.

RS-232 Serial Port

(MiniPlex-2S, MiniPlex-2S/BT)

The RS-232 serial port is galvanically isolated from the multiplexer to prevent ground loops when connected to a computer. Ground loops can result in excessive currents in ground connections, which could destroy the multiplexer or the serial port of the connected computer.

The default speed of the serial port is 38400 Baud. It can be set to any speed in the range from 4800 to 115200 Baud using the MPX-Config utility. It is always best to choose the highest speed possible to prevent any overflows in the multiplexer.

A rule of thumb is to add up the speeds of the inputs and set the output to the nearest higher value. If the inputs are for example set to 38400, 4800, 4800 and 4800 Baud, the sum of these speeds is 52800 Baud. The nearest possible value is 57600 Baud.

In reality, a lower speed is possible because NMEA data is mostly sent in short bursts, resulting in a lower effective speed. It is perfectly possible to leave the serial port at 38400 Baud in the above configuration.

Connect the serial port to a Sub-D9 connector as shown in Figure 5 below. Connections to TxD, RxD and Com are required for proper operation of the multiplexer while the RTS connection is optional.




Figure 5

The serial port supports flow control through the RTS connection. Flow control is needed when waypoints and routes are sent from the computer to a GPS through the multiplexer. While normal NMEA sentences are sent at regular intervals, waypoints and routes are sent in one go without any pause between these NMEA sentences. This fills up the queue in the multiplexer immediately and the multiplexer discards the remaining waypoints and routes. The GPS now only receives a few waypoints and partial routes.

Flow control prevents this from happening. When the queue in the multiplexer is almost filled, the multiplexer deactivates RTS to signal the computer to stop sending data. When the queue is sufficiently emptied, the multiplexer activates RTS to signal the computer to continue. This requires a special setting in your navigation software, which is called "flow control" or "handshake". This setting can mostly be found in the port settings of your software.

Set the flow control to "Hardware" or "CTS/RTS". Do not use "Xon/Xoff" flow control since this uses special characters instead of a signal. These characters are not part of the NMEA standard and therefore ignored by the multiplexer.

USB Port

(MiniPlex-2USB, MiniPlex-2USB/BT, MiniPlex-2Wi)

The USB port is galvanically isolated from the multiplexer to prevent ground loops when connected to a computer. Ground loops can result in excessive currents in ground connections, which could destroy the multiplexer or the serial port of the connected computer.

Because of this galvanic isolation, a MiniPlex-2 with a USB port will not be powered from the USB bus unlike older MiniPlex models. The MiniPlex-2 requires a separate power supply to operate. The USB port however does receive its power from the USB bus. A computer will therefore always show a virtual COM port when the multiplexer is connected, with or without power supply.

The USB port supports flow control. Flow control is needed when waypoints and routes are sent from the computer to a GPS through the multiplexer. While normal NMEA sentences are sent at regular intervals, waypoints and routes are sent in one go without any pause between these NMEA sentences. This fills up the queue in the multiplexer immediately and the multiplexer discards the remaining waypoints and routes. The GPS now only receives a few waypoints and partial routes.

Flow control prevents this from happening. When the queue in the multiplexer is almost filled, the multiplexer signals the computer to stop sending data. When the queue is sufficiently emptied, the multiplexer signals the computer to continue. This requires a special setting in your navigation software, which is called "flow control" or "handshake". This setting can mostly be found in the port settings of your software.

Set the flow control to "Hardware" or "CTS/RTS". Do not use "Xon/Xoff" flow control since this uses special characters instead of a signal. These characters are not part of the NMEA standard and therefore ignored by the multiplexer.

Driver Installation

To use a MiniPlex-2 with a USB port, a driver must be installed. This driver creates a virtual COM port, which can be opened by navigation software.

The CD contains drivers Microsoft Windows (Windows 2000, Windows XP, Windows Vista, Windows 7) and Apple's Mac OS X.

Windows 7

When the MiniPlex is connected to the computer for the first time, Windows will automatically download the most recent drivers from the Windows Update Service if an Internet connection is available. Without connection to the Internet, Windows will eventually tell you that the device driver was not successfully installed.

To install the drivers for the MiniPlex manually, open the Control Panel, choose "System and Security" and then "Device Manager".

The Device Manager will show a "ShipModul MiniPlex-2USB" listed under "Other Devices" as shown in Figure 6

Right-click on the MiniPlex entry and choose "Update Driver Software..." from the menu that appears. This will open the window as shown in Figure 7.




Figure 6

Choose "Browse my computer for driver software".




Figure 7

A new window opens (Figure 8) where you must choose the location of the driver. The driver is located in the subfolder "\USB Driver\Windows" on the MiniPlex Driver & Utility CD.

If you click on "Next", Windows will install the driver.




Figure 8

When Windows has successfully installed the driver, the window as shown in Figure 9 appears.

You can close this window.




Figure 9

The Device Manager will now list a “USB Serial Port” under “Other Devices” (Figure 10). For this port to work, a second driver needs to be installed.

Right-click on the USB Serial Port entry and choose “Update Driver Software...” from the menu that appears. This will open the window as shown in Figure 11.




Figure 10

Choose “Browse my computer for driver software”.




Figure 11

A new window opens (Figure 12) where you must choose the location of the driver again. This time, the location is already set and you can click on "Next".




Figure 12

When Windows has successfully installed the driver, the window as shown in Figure 13 appears.

You can close this window.




Figure 13

The Device Manager will now list a "ShipModul MiniPlex NMEA Multiplexer" under "Universal Serial Bus controllers" and a "MiniPlex Serial Port (COMx)" under "Ports (COM & LPT)".




Figure 14

Windows 2000/Vista/XP

When the multiplexer is connected to a USB port for the first time, Windows will detect new hardware and prompts you for a driver. Insert the supplied CD into the drive and follow the instructions on your screen. If you have an Internet connection, you can let Windows search the Internet for updated drivers. Otherwise, when asked to automatically search for drivers, answer no and choose the option to tell Windows where to find the driver. The driver can be found on the supplied CD, in the folder "\USB Driver\Windows"

The installation on Windows is a two-step process. First, the driver for the multiplexer will be installed. Next, Windows will detect a USB Serial device and will install a second driver. On Windows XP systems, there can be a delay of up to 10 seconds between the installation of both drivers, which sometimes leads to the wrong conclusion that the installation is complete after the first driver is installed. On Windows Vista and Windows 2000 systems, there is only very little delay.

When the installation is complete, a new virtual COM port will be created.

If necessary, the number of this COM port can be changed in the Windows Device Manager. Click on the '+' sign next to the entry marked as "Ports (COM & LPT)". This will expand the entry to list all available COM ports on your computer. The port for the multiplexer is listed as "MiniPlex Serial Port (COMx)" where "COMx" is the name of the newly created serial port.

To change this port number, double click on the "MiniPlex Serial Port (COMx)" entry to open the property page for this port. Next, select the "Port Settings" tab and click on the "Advanced..." button. In the appearing window the assigned port number can be changed. Do not change any other setting in this window.

It is possible to select a port number that is already present on the computer, like COM1. The original COM1 port will then be disabled as long as the multiplexer is connected to the computer. This feature allows the port number to be set in a low range from COM1 to COM4, to accommodate software that only allows COM1 to COM4 to be selected.

More than one multiplexer can be connected at the same time. Every new unit will create a new virtual COM port. Once created, the COM port will always be assigned to the same multiplexer regardless of the USB port being used.

Windows allows a maximum of 256 COM ports. However not all software may be able to select COM ports numbered above COM9.

When installing updated drivers, uninstall the original drivers first with the "Add/Remove Programs" icon in the Control Panel or use the "Update Driver" button on the Driver page of the "MiniPlex Serial Port" property-page.

Mac OS X

The OS X driver is available as a disk image file (.dmg) and can be found on the supplied CD in the "USB Driver" folder. Run the installer by double clicking on the icon. Follow the instructions on the screen. When the installation is complete, plug in the USB cable of the MiniPlex. The MiniPlex will show up in the ports list of your navigation software as MiniPlex-xxxxxxx where the xx's represent the serial number of the MiniPlex.

Bluetooth Interface

(MiniPlex-2S/BT, MiniPlex-2USB/BT)

Using the Bluetooth interface you can connect a host device wirelessly with the MiniPlex. It uses the "Serial Port Profile", which means that this connection is presented on a host as a standard (virtual) COM port. Such a COM port can be opened by any application.

No drivers are required to use a MiniPlex with Bluetooth. As long as the host supports the Serial Port Profile, the only thing you need to do is to pair your device with the MiniPlex. Pairing is a process that connects two Bluetooth devices together by their unique address. Once paired, both devices know about each other and the Bluetooth connection is initiated automatically when an application opens the virtual COM port.

Pairing is initiated on the host by issuing a command like "Find Bluetooth Devices". This operation will show a list of Bluetooth devices in the near surroundings that have responded to the inquiry scan of the host. The multiplexer will be listed as "MiniPlex-2S/BT" or "MiniPlex-2USB/BT". Select this entry and enter the required passkey when asked.

The passkey of the multiplexer is "0000" (four zeros). Most host devices will recognize this and connect without asking you for a passkey. Follow the directions on your device to finish the pairing process. A COM port will now be assigned to the MiniPlex, which can be opened by your navigation software.

In Windows, two COM ports are assigned to the multiplexer, one for outgoing connections and one for incoming connections. You must use the port for outgoing connections in your navigation software.

Network Interface

(MiniPlex-2E, MiniPlex-2Wi)

A network interface connects the multiplexer directly to a network with possibly more than one device. There can be more than one multiplexer connected to a network and/or more than one device that needs to communicate with a multiplexer.

Network Basics

In order to understand how a networked multiplexer works and how to connect to it, it is necessary to know a little bit about IP addresses, port numbers and protocols.

IP Address

Every device on a network needs a unique number to be able to identify that device. This allows us to send a message to one single device on a network. These unique numbers are called MAC addresses and every device in the world that is connected to a network has a unique MAC address. The MAC address of a MiniPlex-2E or -2Wi multiplexer is printed on the serial number label and looks like

00-20-4A-E4-28-58

These addresses are a bit cryptic and not easy to work with. Therefore a mechanism is used to assign a more easy to read number to a device, called an IP address. An IP address consists of four numbers grouped together, separated by dots. Each number can range from 0 to 255. An IP address looks like this:

192.168.1.45

Assigning an IP address to a device could be compared to sticking a coloured label to your house. Now the postman only needs to remember the colour of your label instead of your complete address. Of course, someone needs to manage a list that matches the colour to your address in order to prevent two houses of receiving the same coloured label. Networks and network devices have mechanisms built in that take care of this so we don't have to worry about it (it's called ARP or Address Resolution Protocol).

Netmask

Another tricky bit of networking is a netmask. A netmask basically determines which part of an IP address is the network address and which part is the device address. In its most basic form, a netmask consists of four numbers, similar to an IP address, that are either 255 or 0. And the 255's always come first. A device always has an IP address AND a netmask, for instance:

192.168.1.45 and 255.255.255.0

This combination of IP address and netmask tells us that the first three numbers of the IP address are the network address (192.168.1) and the fourth (45) is the device's address. It also means that this particular combination limits the number of devices on this network to 254 (0 and 255 are reserved).

A network address allows us to send a single message to all devices on the network, instead of sending it to one single device. This is called a *broadcast* (see below). In this example, the broadcast address is 192.168.1.255. The last number here is 255, which means that it targets all devices on the network.

If we have an IP/netmask combination of 192.168.1.45/255.255.0.0, it means the network address is 192.168 and the device's address 1.45, that there are 65534 possible devices (0.0 and 255.254 are reserved) and that the broadcast address is 192.168.255.255.

If you're completely lost at this point, don't worry. Just remember two things:

- all devices on a single network must have the same netmask
- all devices on a single network must have the same network address

So when the netmask for example is 255.255.255.0, the first three numbers of the IP addresses must be the same.

Port Number

A port number can be seen as a sub address within one single device. When a message is sent over the network, it always contains the IP address of the sender, the IP address of the receiver and a port number. This port number is just a logical number that determines the type of data in the message.

Web servers for instance, always listen to messages that have port number 80. If you start your web browser and enter the name of a web site, the request to show the contents of a page is sent to a web server using port number 80. Similarly, your mail program always uses port number 110 to retrieve mail from a mail server and port number 25 to send mail to a mail server.

The use of different port numbers allows us to use the same physical device on a network for different services.

Port numbers are not chosen arbitrarily, they are standardized and controlled by an organization called IANA.

Our multiplexers all use port number 10110, which is a registered port for NMEA data.

Protocols

Two transport protocols are available for sending data over the network: UDP and TCP. UDP can be used in two different modes: Broadcast and Directed.

UDP Broadcast

NMEA sentences are broadcast on the network using UDP messages. Every device on the network will receive these messages. At the same time, any device on the network can send data to the multiplexer, either to its IP address (directed) or as a broadcast. UDP Broadcast has the following properties:

- Every device on the network will receive NMEA data from the multiplexer.
- Every device on the network can send NMEA data to the multiplexer.
- Other MiniPlex-2E/2Wi's on the same network will also receive each other's data. It is therefore possible to send NMEA data over the network from NMEA device to another. Care should be taken to prevent buffer overflows by selectively routing the desired NMEA data to an NMEA output at the receiving end and blocking unwanted NMEA data.
- Routers do not pass UDP Broadcasts from one network to another so this mode can only be used on one network.
- Delivery of NMEA data is not guaranteed, messages can be lost.
- Wi-Fi routers often assign a low priority to UDP broadcasts, resulting in dropped messages. Typically up to 5% of the messages gets lost.

UDP Directed

With directed UDP data is sent to a specific IP address. The advantage is that it travels across routers and networks and can therefore also be used to send NMEA data over the Internet. Any device on the network can send data to the multiplexer either to its IP address (directed) or as a broadcast. Directed UDP has the following properties:

- Travels across routers/networks and the Internet.
- Higher chance of delivery than UDP broadcast.
- Every computer on the network can send NMEA data to the multiplexer.
- Only one computer can receive NMEA data from the multiplexer.
- Delivery of NMEA data is not guaranteed, messages can be lost.

TCP

When using TCP, a device sets up an exclusive connection with the MiniPlex. The TCP protocol is reliable, which means that when data gets lost on the way from one device to another, it is automatically retransmitted. Both the MiniPlex-2E and the MiniPlex-2Wi are limited to one TCP connection at a time.

TCP has the following properties:

- Travels across routers/networks and the Internet.
- Only one computer or other device may communicate with the multiplexer.
- Reliable connection. Lost messages are automatically retransmitted.

Although TCP might seem the best option from the above, it is favourable to use UDP. Compared with TCP, UDP will minimize network bandwidth. To send periodically updated sensor data, it is usually more appropriate to NOT use a guaranteed-delivery protocol like TCP. In navigation applications, the best thing to do in the rare event that a message doesn't get through is to simply wait for the next message. The TCP protocol forces retries that increase network traffic unnecessarily.

UDP resembles NMEA the most because NMEA is also a message based broadcast protocol without any acknowledgements or retries.

Assigning IP addresses

When devices are connected to a network, they all must have a unique IP address and a matching netmask. One way of achieving this is to set the IP address and netmask of each device manually. The other way is to let a DHCP server take care of this.

DHCP is an acronym for Dynamic Host Configuration Protocol and it is a mechanism to automatically assign IP addresses to devices (hosts) on a network. A DHCP server on a network will respond to requests from DHCP clients to obtain an IP address.

In a typical network environment, a router acts as a DHCP server while other devices such as computers, laptops, tablets and smartphones are DHCP clients, receiving IP addresses from the DHCP server. This ensures that you can connect these devices to the network without worrying about IP addresses, netmasks and gateways - all of this is taken care of by the DHCP server.

The MiniPlex-2Wi acts as a WiFi access point with a DHCP server built-in. When a device joins its WiFi network, it will automatically receive an IP/netmask from the MiniPlex-2Wi. The only thing you have to do is to enter the fixed IP address of the MiniPlex-2Wi (10.0.0.1) in your navigation software.

The MiniPlex-2E is completely different in this respect. It has a DHCP client and thus relies on a DHCP server already present on the network to obtain an IP/netmask automatically. If no DHCP server is present, you have to manually assign an IP/netmask. This is the case for instance, if your "network" is just the MiniPlex-2E and a computer. Obviously you will need to assign a manual IP address and netmask to your computer too in this case.

Auto-IP

When DHCP request remains unanswered, a device assigns itself an IP address in the range of 169.254.0.0 to 169.254.255.254 with netmask 255.255.0.0. This is called an Auto-IP address. Although two devices with an Auto-IP address on the same network can perfectly communicate with each other, this is not a desired situation because these addresses are assigned totally at random. So every time a device powers up, the address changes within the Auto-IP range and you'll never be sure of its IP address. Also, the time it takes for a device to auto-assign varies wildly from a few seconds to over a minute.

MiniPlex-2E Network Setup

When you are going to use a MiniPlex-2E, it is important to know whether your network has a DHCP server. If a DHCP server is present on the network, you don't need to manually assign a fixed IP address to the MiniPlex-2E if the following conditions are met:

- The DHCP server always assigns the same IP address to the same MAC address
- The DHCP pool of free addresses will never be exhausted

This ensures that the MiniPlex-2E will always get the same IP address. The best practice however is to assign a fixed IP and netmask to the MiniPlex-2E.

In order to find the MiniPlex-2E on the network, first select UPD with the Port selector in the "MiniPlex Connection" box. After this, the Tools menu will show a "MiniPlex-2E" sub-menu. From this sub-menu, select "Search..."

This will bring up a window showing the MiniPlex-2E's found on the network (Figure 15). In this case there's only one and its IP address appears to be 192.168.1.95. The cryptic number in brackets is the MAC address of the multiplexer, which is also printed on the serial number label. If you select this entry and click OK (or double-click on the entry), the window closes and the IP address is transferred to the Host field in the "MiniPlex Connection" box. At this point you can click on the Connect button to open a connection with the multiplexer and the MPX-Config window should show some NMEA sentences in the NMEA viewer.

If the listed address is an Auto-IP address in the 169.254.x.x range, click on the "Change IP Address" button to assign a sensible IP address to the MiniPlex. When done, the window will show the MiniPlex with the newly assigned address and it can be selected for normal use. You can use the "Factory Reset" button to restore the network settings to its factory defaults if necessary (DHCP and UDP broadcast).




Figure 15

If you're happy with the DHCP assigned IP address and the default UDP broadcast mode, there is no further network configuration required and you can proceed with the normal multiplexer configuration as outlined in chapter "MPX-Config" on page 28.

To change any of the network settings, make sure the IP address of the multiplexer is in the Host field in the "MiniPlex Connection" box and select menu Tools → MiniPlex-2E → Network Setup... This will open the "MiniPlex Network Settings" as shown in Figure 16.

These are the factory default settings. The IP address shown here is 0.0.0.0, which means the multiplexer is set to DHCP. This address is different from what you have entered in the Host address field on the main window because that is the address that the MiniPlex received from the DHCP server.

You can now enter the desired IP address and a netmask that matches your network. The Gateway IP can be left to 0.0.0.0 if you are not going to set the multiplexer to UDP Directed.

The example in Figure 17 show fixed IP settings and TCP protocol enabled.

If you set the multiplexer to UDP Directed, you must enter a destination IP address in the Destination field. If this IP address is not on the same network as the multiplexer, you must also enter the address of your network gateway in the Gateway IP field.

Please note that when UDP Directed is enabled, you will not receive any NMEA data from the multiplexer anymore when the IP address of your computer is different from the Destination IP. The network settings however can always be changed regardless of this setting.

If you click on the OK button to activate the settings, a progress bar will appear because the network interface must be restarted and this takes approx. 7 seconds. The new IP address and protocol will appear automatically in the Host and Port controls on the main window of MPX-Config when the process is completed.

If you need to change the network settings back to DHCP, set the IP Address field to 0.0.0.0 and click OK.

In some cases, the settings of the multiplexer cannot be verified after change, for instance because the IP address is changed from a fixed address to DHCP (0.0.0.0) or when an IP address is entered which is not on your network. In this case, a warning will appear.

Search

The search function (menu Tools → MiniPlex-2E → Search...) will almost always find any MiniPlex-2E on the network, even if it has been configured with the wrong IP/Netmask combination for the network it is connected to. In rare cases MiniPlex-2E cannot be found. See the paragraph "Network Recovery" below how to deal with this situation.

The search result window (Figure 18) has two buttons that allow you to restore the network settings to the factory default values and to change the current IP address in case it is outside your network. In that case the normal network setup cannot be used.




Figure 16




Figure 17




Figure 18

Network Recovery

In rare cases a MiniPlex-2E might not show up in the search results window due to a possible misconfiguration in the Network Settings. This might happen when duplicate IP addresses exist on the network or the multiplexer has an illegal IP address. To recover from such a situation, a new IP address can be assigned with menu option "Tools → MiniPlex-2E → Assign IP".

In the "Assign IP Address" dialog (Figure 19), enter the MAC address of the multiplexer. This MAC address can be found on the label on the topside of the multiplexer, below the serial number. Enter the MAC address with the fields separated by dashes as shown. Then enter a valid IP address and click on OK. A progress bar will appear during the update process, which will take approximately 10 seconds. After that, the multiplexer can be reached again through the normal "Network Settings" dialog.




Figure 19

WiFi Interface

(MiniPlex-2Wi)

Through its WiFi interface, the MiniPlex-2Wi can communicate with wireless devices like an iPad, iPhone, a PC or a Mac.

WiFi Access Point

The MiniPlex-2Wi provides a wireless access point through its 802.11b+g interface with the following parameters:

SSID (name): MiniPlex-2Wi:xx:xx
IP address: 10.0.0.1
Port: 10110
Protocol: TCP/IP
DHCP server enabled
No security or encryption

The xx:xx's are the last two bytes of the MAC address of the multiplexer as printed on the serial number sticker. This uniquely identifies a MiniPlex-2Wi from similar devices.

On an iPad for instance, the MiniPlex-2Wi will appear as shown in Figure 20.



Figure 20

Simply tap on the MiniPlex entry to connect to the MiniPlex. No further configuration is required.

The built-in DHCP server automatically assigns IP addresses to devices that connect wirelessly to the MiniPlex-2Wi. It is not necessary to make any settings in the network configuration of your wireless device. Up to 7 devices can be connected simultaneously.

The access point also provides routing, which means that all connected devices can also communicate with each other using TCP or UDP.

The NMEA data from the multiplexer is available on the WiFi network as UDP Broadcast or TCP on port 10110. Every device on the network will receive this data and every device can also send data to the network using UDP.

The MiniPlex-2Wi also supports TCP but this is limited to one connection only. As soon as one device opens a TCP connection to the MiniPlex-2Wi, the UDP broadcasts will stop and no other device will receive NMEA over UDP anymore until the TCP connection is closed again.

The specific advantages and disadvantages of TCP and UDP are explained in chapter "Protocols" on page 16.

In your navigation application, you need to enter the IP address of the MiniPlex-2Wi, which is 10.0.0.1. The port number to use is 10110. Figure 21 shows the settings in iNavX®.




Figure 21

The WiFi interface and the USB port operate simultaneously and with the same priority. This allows an on-board fixed computer to be connected simultaneously with a wireless device.

The WiFi interface cannot be used to update the firmware of the MiniPlex-2Wi or to configure the WiFi interface using \$PSMDWI commands (see the Technical Reference, Proprietary NMEA Commands). Only the USB interface can be used for this.

NMEA Ports

The NMEA ports are the inputs/listener ports and outputs/talker ports on the MiniPlex-2 that are used to connect to navigation instruments, chart plotters etc. There are many interpretations and variations of NMEA ports so we'll explain a few things first.

NMEA Signals

Although the NMEA 0183 standard specifies the signal names, voltage levels and connection methods very clearly, the reality is far from this ideal world.

The most important property of an NMEA port is that the connections or wires are labelled A and B and that it uses a differential signalling scheme. This means that data is transmitted on both wires, but in "opposite direction". Both wires are driven between 5V and 0V and opposite of each other. This means when wire A is at 5V, then wire B is at 0V and when wire A is at 0V, then wire B is at 5V. The advantage of this signalling scheme is that it is very insensitive to electrical interference.

NMEA A and B are often labelled as NMEA + and - respectively. When connecting devices, simply connect NMEA A to NMEA A or NMEA + and NMEA B to NMEA B or NMEA -.

Things get complicated when manufacturers don't follow the NMEA 0183 standard, which is very often the case. Many devices have an NMEA interface, which is actually an RS-232 interface. The only resemblance with the NMEA standard is the format of the data transmitted. Electrically, they are an entirely different world. The used signal names differ wildly and often lead to confusion. When a device has a NMEA input with connections "Data In" and "Data Return" it is often not clear whether this input is galvanically isolated or if "Data Return" is simply another name for "Signal ground".

Instead of being fully compatible with the NMEA standard, many devices use a single-ended signalling scheme where data is transmitted on one signal wire while the power ground presents the return path for data. Single ended devices often have connection names like TX and Gnd (transmit and ground) on the NMEA output and RX and Gnd (receive and ground) on the NMEA input. Also used are Data Out, Data In and Signal Ground. Mix these with standard NMEA connections and confusion is imminent!

In general it is easy and safe to connect a single-ended output to a differential input. How to connect a differential output to a single ended input however is less obvious. When NMEA B of an output is connected to the signal ground of an input, the B signal is actually short-circuited to ground. A properly designed output can handle this abuse but it will result in fairly high currents in cables, which in turn can lead to severe interference on SSB and VHF radios. In the worst case, the output will be damaged.

To overcome this problem, the MiniPlex multiplexers provide a Com terminal on each output in addition to the A and B terminals. This Com terminal is similar to a signal ground. To connect an output of the MiniPlex to a differential NMEA input, use the A and B terminals. Use the A and Com terminals to connect to a single-ended NMEA or RS-232 input.

NMEA Inputs

The MiniPlex-2 has four NMEA inputs called In1 to In4. Each input should be connected to one output only. These inputs are galvanically isolated from the multiplexer, as specified in the NMEA 0183 standard.

The default communication speed of the NMEA inputs is 4800 Baud (NMEA standard) and it can be set to any value from 4800 to 57600 Baud using MPX-Config. Set the speed of an input to 38400 Baud if it will be connected to an AIS receiver or transponder.

Connect the A and B terminals of the NMEA input on the multiplexer to the A and B terminals of the NMEA output on the instrument as shown in Figure 22 on the left. These terminals may also be labelled as Data+/Data-, TX+/TX-, Out+/Out- or ve+/ve-.

Some instruments have single ended outputs with only one data terminal. Connect this terminal to the A terminal of the multiplexer input, and connect the ground of the instrument to the B terminal of the multiplexer output as shown on the right in Figure 22. The instruments data ground is often combined with its power supply ground. In that case, connect the power ground of the instrument to the B terminal of the multiplexer input.




Figure 22

NMEA Outputs

The MiniPlex has two NMEA outputs called Out1 and Out2. Each output is capable of driving up to four NMEA inputs.

The default communication speed of NMEA Out1 is set to 4800 Baud and NMEA Out2 is set to 38400 Baud. The speed can be set to any value from 4800 to 115200 Baud using MPX-Config.

Connect the A and B terminals of the NMEA output on the multiplexer to the A and B terminals of the input(s) on the instrument(s). These terminals may also be labelled as Data+/Data-, RX+/RX-, In+/In- or ve+/ve-.

Some instruments may have single ended inputs, with only one data terminal. Connect this terminal to the A terminal of the multiplexer output, and leave the B terminal of the multiplexer output unconnected. Connect the ground of the instrument to the Com terminal of the multiplexer output. Figure 23 shows several examples of differential and single ended connections and combinations of both.

Warning

When using a single ended connection, the instruments data ground is often combined with its power supply ground. In this case, it is very important to add an **extra wire between the Com terminal and the Gnd terminal** of the multiplexer. If you fail to do this, the multiplexer may be damaged!




Figure 23

The shield terminals on the multiplexer (Shld) can be connected to the shield of the cable if available. This should always be done on one end of the cable only, preferably on the end that is connected to an NMEA output.

Combining Ports

It is sometimes necessary to combine an input and an output of the multiplexer to connect to an instrument. One of the most common cases is the connection between a GPS and the multiplexer. While some GPS receivers have properly designed NMEA ports, many only have an RS-232 port which is single ended with three terminals: TxD (data out), RxD (data in) and Ground. Figure 24 shows how to connect such a GPS to the multiplexer.




Figure 24: Connecting a GPS with a serial port to the multiplexer.

SeaTalk

SeaTalk® is a proprietary protocol developed by Raymarine®. This protocol is used for communication between Raymarine navigation instruments like the ST40, ST50 and ST60 series.

To be able to use these instruments with commonly available navigation programs or to feed their data into other non-Raymarine instruments, the SeaTalk data needs to be translated into NMEA. Even Raymarine's own navigation software, Raytech Navigator, needs this translation.

The MiniPlex can be directly connected to a SeaTalk network. It will translate all SeaTalk data required for navigation into NMEA sentences. Input In 4 can be set to SeaTalk mode ("SeaTalk -> NMEA") and should be connected as shown in Figure 25.

Note that the **red** and **yellow** wires are used! The shield of the SeaTalk cable is not connected to the multiplexer.




Figure 25

Figure 26 shows how to power the MiniPlex from the SeaTalk network. The red wire is connected to both In4A and the power terminal and the shield of the SeaTalk cable is connected to the power ground terminal.




Figure 26: Power and data from the SeaTalk network.

Power Supply

The multiplexer must be powered from an externally supplied DC voltage from 8 to 35V. The power supply connection is protected against reversed polarity.

Indicators

The LEDs on the MiniPlex provide information about the status and operation of the multiplexer. When the multiplexer is power up, all LEDs flash once.

- Green: This LED flashes upon reception of a valid NMEA sentence. It also shows a dim flash every 2 seconds to indicate the multiplexer is powered and operating correctly. During a firmware update, the LED flashes upon reception of a firmware block.
- Red: This LED flashes on a buffer overflow, indicating that a currently received NMEA sentence will be lost.
During start-up, this LED is on for a short moment while the multiplexer checks if firmware is loaded or if a firmware update is initiated by MPX-Config. If firmware is found, the LED goes off. When the LED stays on, no firmware was found.
During a firmware update, the LED is on. When the update is completed, the LED goes off. If the LED stays on after a firmware update error, it indicates that no valid firmware is present. When the multiplexer is set to Terminal Mode (MiniPlex-2Wi only) with the PSMDWI,T command, this LED is blinking continuously.
- Yellow: This LED is only present on the MiniPlex-2Wi and indicates the status of the WiFi connection. When off, no device is connected to the WiFi access point. When on, one or more devices are connected and receiving UDP data. The LED blinks when a TCP connection is active.

Data Throughput

A multiplexer is not the Holy Grail for connecting NMEA devices. It should be fairly obvious that if a device combines data from four sources, the total amount of data that must be forwarded is the sum of the amount of each source. Still, the NMEA standard specifically limits the communication speed to 4800 Baud or bits per second, which equals 480 characters per second.

So, when using a multiplexer, a situation could arise where more data is received than can be transmitted because of the speed limitations of the NMEA outputs. Such a situation will lead to an overflow of the input queues of the multiplexer.

When an NMEA sentence is being received while a queue is filled up, this sentence is discarded because the MiniPlex only forwards complete NMEA sentences. This event is indicated by a blink of the red LED. The indicators in the "Input Overflow" section of MPX-Config will also show this event.

In its default factory setting, as shown in Figure 27, the data flow through the MiniPlex is very straightforward: the data that is received on the NMEA inputs is always sent to the host interface(s).




Figure 27

In addition to this, the same data is also sent to Out2, as indicated by the checkboxes in the section "Input Settings". The section "Output Settings" shows that data from the computer (Host Data) is sent to Out1 only.

This basic configuration allows you to combine data from navigation instruments and send it to a computer using the host port(s) and to a chart plotter connected to Out2, while at the same time the computer can control an autopilot connected to Out1.

The default speed setting of the inputs and outputs ensures that there will be no queue overflows.

Please note that the default communication speed of Out2 is 38400 baud. Most chart plotters support this high speed for reception of AIS data. However, if you want to connect this output to a repeater display or a VHF radio, the speed of Out2 must be lowered to 4800 baud. If this leads to excessive overflows, it is necessary to reduce the amount of data sent to this output. This can be achieved by changing the default routing settings (disable certain inputs for Out2) or by using the Sentence Filtering & Routing facility of the MiniPlex.

Now back to data throughput. The standard speed of an NMEA port is 4800 Baud or bits/second, representing 480 characters per second. It is quite obvious that when four inputs receive data at 480 char/s and all of this data must be sent out again on an output with the same bandwidth of 480 char/s, a huge problem will arise. In the default configuration of Figure 27, this problem does not occur because the speed of Out2 is set to 38400 Baud (3840 char/s). When Out2 is not used, set it to the highest speed or disable routing of any of the inputs to Out2. When Out2 is connected to a chart plotter, try to choose the highest speed the plotter is capable of.

If data from more than one input needs to be routed to an output operating at 4800 Baud, problems with data throughput can arise when too much data is sent to this output.

NMEA data tends to be sent in bursts. Some devices like depth sounders or wind instruments only send one sentence per second. A GPS however may send bursts of up to 13 sentences every two seconds. While the average throughput over time may be low, an input might fill its queue quite rapidly when a burst of sentences is received. The queues in the MiniPlex are quite large and may contain up to 30 sentences of GPS data.

A couple of occasional blinks of the red LED over a period of a few seconds means that large bursts of sentences are received and a queue is hitting its limit. Some sentences are discarded but most of them will be forwarded without problems. Such a situation is totally acceptable and would mean that for instance one depth, wind or position update is missed every few seconds.

A quite different situation may arise with some fluxgates or gyrocompasses. These devices may send their heading sentences with a speed up to 40 sentences per second! Instead of queuing a burst of sentences every one or two seconds, the multiplexer must queue a constant stream of sentences, possibly utilizing the maximum bandwidth of the multiplexer. Such a situation can lead to a queue that is constantly filled up to its maximum capacity. This in turn results in heading data that can be up to 20 seconds old when it is forwarded, which is totally unusable for any autopilot to steer on. Enabling the "Real Time" option for this input can solve this specific problem. This option bypasses the queue entirely. Only one sentence will be stored and forwarded when the time slot for this input arrives. Outside its time slot, incoming sentences will be discarded. A lot of heading sentences will be lost now but the ones that are forwarded are done so almost immediately. Hence the name "Real Time".

When the red LED is blinking severely or stays on almost continuously, it is strongly recommended to investigate which instrument or input leads to this overflow. The MPX-Config utility will show on which input the overflow occurs by a blinking indicator in the "Input Overflow" section. Opening the Statistics window (Figure 28) from the Tools menu will give an insight about the amount of data in each queue and whether it is filled constantly or occasionally.

Some general rules apply for reducing overflow situations. A simple rule of thumb is that an overflow can never occur if the speed of an output is equal to or higher than the combined speeds of all inputs that are routed to that output. For example: if the multiplexer is in its default configuration and all four inputs are set to 4800 Baud, the minimum output speed equals $4 \times 4800 = 19200$ Baud. This rule is only a hard rule when the input bandwidth is fully utilized i.e. an instrument is sending data continuously. This is hardly ever the case. As mentioned earlier, NMEA data is often sent in bursts, resulting in a much lower overall bandwidth. It could be perfectly feasible to have a system with four instruments connected to the multiplexer, while running all in- and outputs on 4800 Baud without a single overflow.




Figure 28

There are several ways to resolve overflow situations:

1. Configure the instruments on the listener ports to send less data or with greater intervals. GPS receivers can sometimes be configured for this.
2. Use the sentence filter of the multiplexer to block unwanted sentences. Unwanted sentences are discarded immediately and do not occupy queue space or bandwidth.
3. For sentences that should not be blocked, setting a divisor in the sentence filter may lower their rate. A gyro may be throttled down to 10 sentences per second or even less. From the GPS output, the rate of the sentences containing satellite information could be lowered to once every 10 seconds instead of being output every time a position is output by the GPS.
4. Use the routing options to select which input is routed to an output or use the routing options in the sentence filter to selectively route NMEA sentences to an output.
5. Increase the speed of the NMEA output that causes the bottleneck. This will only work when the connected equipment also supports higher communication speeds.

MPX-Config

The multiplexer can be configured with a configuration program called MPX-Config. This program can be found on the accompanying CD. There is no installation procedure for this program, just start it from the CD or copy it to a suitable folder on the hard disk of your computer and start it from there.

The multiplexer itself is configured with proprietary NMEA sentences. MPX-Config sends these sentences to the multiplexer when you change a setting.

All configuration settings are stored in the multiplexer's non-volatile memory. These settings are retained without power supply.




Figure 29: MPX-Config main window

The window of MPX-Config is divided into four sections from top to bottom: the menu, the NMEA viewer, the controls and the status bar. The menu basically controls the MPX-Config program. The NMEA viewer shows the NMEA sentences that are received from the multiplexer. These sentences include the NMEA data received by the multiplexer on its inputs as well as status messages generated by the multiplexer (sentences starting with \$PSMD). The controls determine the operation and configuration of the multiplexer. The status bar shows the name or type of multiplexer that is connected, its internal software (firmware) version number and its serial number. This information is useful when you need technical support. Also shown are the optionally loaded or saved configuration file and a line counter when you have started a log file.

Menu

The menu contains two sub-menus: File and Tools. Some options of these menus are disabled or not visible, depending on the type of connected multiplexer or on the status of the connection.

The File menu offers the following choices:

Log NMEA...	Start writing NMEA data to a log file. A log file is a plain text file and can later be opened by any text editor to examine the data. The Log counter on the status bar will show the number of NMEA sentences that are currently written to the log file.
Log Diagnostic Info...	Start writing to a log file with the addition of a time stamp at the beginning of each NMEA sentence.
Stop Log	Stop writing NMEA data to the current log file and close that file.
Load Configuration...	Load a previously saved configuration file into the multiplexer. The current configuration will be overwritten. A configuration file stores all settings made with MPX-Config.
Save Configuration	Save the current configuration to a previously file.
Save Configuration As...	Save the current configuration to a new file.
Update MiniPlex Firmware...	Load new a firmware file into the multiplexer. This option will only be visible when your multiplexer supports firmware updates. This is the case from firmware version 3.00 and up. Multiplexers containing lower firmware versions need to be returned to our factory for an update.
Update WiFi Firmware...	Load a new firmware file into the WiFi module.
Exit	This exits MPX-Config.

The Tools menu offers the following choices:

Show Statistics	Opens a window showing bars that indicate how much NMEA data is stored in the input queues. This is a useful option for diagnosing data congestion and overflow situations as mentioned in paragraph "Data Throughput". A queue that is filled constantly can lead to unacceptable delays in data transfer.
MiniPlex-2E	Opens a sub-menu for the MiniPlex-2E.
Reset Factory Settings...	Reset the multiplexer to its default factory configuration.
About	Show a window with version information.

The MiniPlex-2E sub-menu offers the following choices:

Network Setup...	Open a window to setup the network parameters of a MiniPlex-2E.
Search...	Search the network for MiniPlex-2E's. A window is shown with the search results.
Assign IP...	Assign an IP address to a MiniPlex-2E using its MAC address.

Controls

MiniPlex Connection

Before being able to configure the multiplexer, a connection must be set up. Use the Port selector either to select the COM port of the multiplexer or to select TCP or UDP when using a network connection.

COM Port

When a COM port is selected, a speed setting appears which allows you to select the communication speed of the COM port (Figure 30). When using a multiplexer with a serial port, the speed must match that of the multiplexer.

The factory setting of the MiniPlex-2S(/BT) is 38400 Baud. When the communication speed is unknown, select Automatic.

Click on the Connect button to initiate the connection. When Speed is set to Automatic, MPX-Config will attempt to connect at all possible speeds until a response from the multiplexer is received.

When the selected COM port is a virtual COM port of a USB or Bluetooth connected multiplexer, the speed setting is irrelevant and will be disabled once a connection is established.




Figure 30

Network

When a network connection is used to connect to a MiniPlex-2Wi or a MiniPlex-2E, select TCP or UDP as shown in Figure 31. When connecting to a MiniPlex-2Wi, you can select either UDP or TCP. When connecting to a MiniPlex-2E, use the protocol as set in the "MiniPlex-2E Network Setup" on page 17.




Figure 31

When TCP or UDP is selected, a Host field appears where you must enter the IP address of the multiplexer. For a MiniPlex-2Wi, this address is always **10.0.0.1**

In case of a MiniPlex-2E, enter the address as specified in the "Network Setup". Click on the Connect button to initiate the connection.

Reading the configuration

When the Connect button is clicked, MPX-Config opens the connection to the multiplexer and automatically retrieves its current configuration. The tabbed configuration pages will be enabled upon success and the LED on the Connect button will become green.

If a "Multiplexer does not respond" message appears, you may have selected the wrong COM port. An "Unable to connect" message indicates a wrong IP address.

If you exit MPX-Config, the connection settings will be saved and reloaded with the next start of MPX-Config. When you select a different port while being connected, MPX-Config disconnects from the multiplexer.

You can also instruct MPX-Config to retrieve the configuration from the multiplexer with the "Read Configuration" button (Figure 32).

Manual NMEA input

MPX-Config allows manual entry of NMEA sentences for testing, configuration etc.

Type the desired NMEA sentence in the edit box and click on the Send button or press the enter key. MPX-Config will keep a history of entered sentences/commands. These can be selected by clicking on the small arrow. A selected sentence can be sent again by clicking on the Send button or pressing the Enter key. It can also be edited prior to sending.

Preceding the NMEA sentence with a \$ is optional, MPX-Config will add it if omitted. The input is case sensitive, so whatever you type will be sent to the multiplexer literally. Since all NMEA sentences are uppercase, you have to enter them as uppercase.

Any sentence starting with \$PSMD will be recognized by the multiplexer as a configuration command and will be processed as such. Any other sentence will be sent to the NMEA outputs.




Figure 32

Viewer Options

The NMEA Viewer area (Figure 33) offers a few controls that make observing NMEA data easier.

Clear

This button clears the NMEA Viewer window.

No Scroll

When this option is enabled, a list of incoming NMEA sentences will be displayed that will be refreshed constantly when new similar sentences are received. A scroll bar will appear when the list grows beyond the length of the viewer area. This feature allows you to closely examine the types of sentences that are received from the connected instruments. Any proprietary NMEA sentences that are generated by the multiplexer are also listed. These sentences start with \$PSMD.

Tag Blocks

This option will show any TAG blocks that precede a sentence. TAG blocks can be seen when they are enabled (see "Channel Information"), when the input selector is set to a specific input or when the Capture function of the sentence filter is activated. Of course, when a device that is connected to the inputs of the multiplexer sends TAG blocks, they will also be visible.

Input selector

The input selector allows you to selectively see sentences of one specific NMEA input of the multiplexer or form the conversion results. Setting this selector to any setting besides "All Inputs" will enable TAG blocks. These are used to identify the input a sentence is received on. When set to "All Inputs", the original TAG block setting is restored.

Overflow

The overflow indicators show which input suffers from a queue overflow (inputs 1 to 4 from left to right). See the section "Data Throughput" on page 26 for ways to prevent overflow situations with different instruments.




Figure 33

NMEA Inputs/Outputs

This page allows you to set the communication speeds of the NMEA inputs and outputs of the multiplexer, various options related to the inputs or outputs and the default routing of NMEA sentences. The settings are grouped together for the inputs and the outputs.




Figure 34

Speed

This sets the speed of each NMEA input or output. 4800 Baud is the standard speed for navigation equipment. Some fluxgate or gyrocompasses operate at 9600 Baud to accommodate the higher throughput of 20 headings per second or more. AIS equipment operates at 38400 Baud.

If you change the speed of In4, the speed of Out1 will be changed too. In4 and Out1 share the same communication port inside the multiplexer and therefore always have the same speed. Out1 is generally used to control an autopilot and should be left at 4800 Baud for this purpose. The settings for In4 and Out1 are disabled and fixed to 4800 Baud when SeaTalk translation is enabled.

Care should be taken when selecting other speeds than 4800 Baud with respect to possible queue overflows. See the paragraph "Data Throughput" on page 26 for more information.

Talker ID

The multiplexer can change the Talker ID of incoming sentences. The first two characters of an NMEA sentence represent the Talker ID, indicating which instrument (talker) has sent this sentence. Normally you don't need to change this and these fields can be left blank ("--").

Changing the Talker ID of a sentence might be necessary for instance when using a GPS compass. Such a compass often outputs a true heading sentence starting with \$GPHDT. Many instruments or navigation programs however require a true heading that starts with \$HE, which is the standard Talker ID for true heading devices. By entering HE in the Talker ID field of the input connected to the GPS compass, the incoming \$GPHDT sentence will be changed into \$HEHDT.

Setting a Talker ID can also be useful when similar instruments are connected to the multiplexer while the navigation software must be able to distinguish between the data from these instruments. A catamaran for instance could have a depth sounder in each hull, sending similar sentences to the navigation software. Setting the Talker ID for those inputs to H1 and H2 respectively allows the software to recognise both depth readings separately.

Proprietary sentences do not have a Talker ID and are thus unaffected by this option.

Enter the Talker ID in the edit box of the desired input and press the Enter to send the setting to the multiplexer. A Talker ID may consist only of upper case characters and numbers. See the Technical Reference section for an overview of the most commonly used Talker ID's.

When the Talker ID is changed, the background turns yellow to indicate that the modified Talker ID has not yet been sent to the multiplexer. Pressing Enter will send all Talker ID's to the multiplexer and the background colour will return to white again. It is possible to change all Talker ID's first and press Enter after changing the last one. Starting at the Talker ID field of input 1, pressing the Tab key will jump to the Talker ID of the next input.

Clicking the "Read Configuration" button will read the Talker ID settings from the multiplexer. Any modified Talker ID's that have not been sent to the multiplexer (yellow background) will revert to their original values. To clear a Talker ID, simply clear the edit box(es) by selecting them with the cursor and press the Del or Backspace key on your keyboard and finally press Enter. An empty Talker ID setting will show two dashes.

Real-Time

The "Real-Time" option bypasses the queue of an input. All incoming NMEA sentences are stored in a queue - one for each input. Each queue can store several NMEA sentences, waiting to be forwarded. A GPS for instance can send up to 13 sentences at once every one or two seconds, and a queue can store these sentences until they are processed and forwarded.

An electronic compass however, only sends one heading sentence each time but at a rate of up to 20 sentences per second. This high rate will fill up a queue rapidly with a lot of heading sentences. When these sentences are retrieved from the queue to be forwarded, they may contain a heading that is lagging several seconds behind the current heading - too much for a reliable indication or for an autopilot to steer on. This situation will also be indicated by the overflow LED on the multiplexer and the indicators in the "Input Overflow" section of MPX-Config.

When the "Real-Time" option is enabled, the queue for that input is bypassed. Only one single sentence will be stored, waiting to be forwarded almost immediately. The result is that some heading sentences will be discarded but the ones that are forwarded have no significant delay.

This option should be used only for instruments that output one single sentence like an electronic compass. If this option is enabled for a GPS, only the first sentence of an entire group will be passed, the rest will be discarded.

To Output 1 & 2

These options allow you to set the default route from the NMEA inputs to the NMEA outputs. The default route as shown in Figure 34 routes all inputs to Out2 and none to Out1. By default, the NMEA inputs are always routed to the host ports.

The default route is applied to an input when no specific route for that input exists in the sentence filter. A match in the sentence filter always takes precedence over the default route.

Input Mode

The inputs of the multiplexer can be set to different modes besides standard NMEA, to be able to accept "not quite standard" NMEA, plain text or SeaTalk. The following modes are supported:

- NMEA:** Normal NMEA processing. This is the default processing mode which checks sentences for correct formatting. They must start with a '\$' or '!' character and end with a Carriage Return (CR) and a Line Feed (LF) character in that order. If a sentence contains a checksum, the checksum of the sentence is calculated and compared with the checksum field of the sentence. If all of the conditions above are met, the sentence is passed. Otherwise it is rejected. This processing meets the IEC/EN60945 standard.
- NMEA (ERR):** Pass NMEA sentences that contain a checksum error unmodified, bypassing all further NMEA processing and filtering. Only the default route is applied.
- NMEA (CR/LF):** Relaxed NMEA format checking. This will pass a sentence that is incorrectly terminated. A sentence is considered correctly terminated as long as it ends on a CR, a LF or a combination of both in arbitrary order.
- Text to NMEA:** Accept a plain text string and forward it in a standard NMEA \$--TXT sentence. Any character with an ASCII value > 32 (a space) is considered to be the start of a string. The string must end on a CR or LF and may not be longer than 61 characters. A longer string is discarded. Only valid NMEA characters are passed. Invalid characters are stripped from the input data.
The Total number and Sentence number fields are always set to '01'. The Text Identifier field of the \$MXTXT sentence contains the input number on which the text was received. When for instance 'Hello World' is received on input 3, the resulting sentence will be: \$MXTXT,01,01,03,Hello World*6E.
- Text to PTXT:** Accept a plain text string and forward it in a \$PTXT sentence. Any character with an ASCII value > 32 (a space) is considered to be the start of a string. The string must end on a CR or LF and may not be longer than 61 characters. A longer string is discarded. All characters with an ASCII value from 32 to 127 are passed.
- Plain Text:** Accept a plain text string and forward it as a plain text string. Any character with an ASCII value > 32 (a space) is considered to be the start of a string. The string must end on a CR or LF and may not be longer than 61 characters. A longer string is discarded. All characters with an ASCII value from 32 to 127 are passed. The multiplexer will always end a forwarded string with a CR/LF pair.
- SeaTalk:** This option enables translation of SeaTalk® data that is received on In4 into NMEA sentences.
SeaTalk is a proprietary protocol developed by Raymarine and it is used for data exchange between Raymarine navigation instruments like the ST40, ST50 and ST60 series. To be able to use these instruments with commonly available navigation programs or to feed their data into non-Raymarine instruments, the SeaTalk data needs to be translated into NMEA sentences. See the Technical Reference section for an overview of translated SeaTalk data.
Selecting this option will automatically set the communication speed of In4 and Out1 to 4800 Baud and disable the speed setting.

NMEA Conversions

The results of NMEA conversions (see Options page, Figure 36) are available as if they were received on a separate – virtual - input. This input is subjected to the same routing and filtering functions as the real inputs.

Host Data

This controls if and how the data from the host interfaces is sent to both NMEA outputs. Possible options are No, Yes or Override.

- No:** No data from the host is sent to the NMEA output.
- Yes:** Data from the host is sent to the NMEA output and mixed with data from the inputs.
- Override:** Data from the host is sent exclusively to the output and takes precedence over the data from the inputs. When the host sends data to the multiplexer, no input data is sent to the output. When the host stops sending data however, data from the inputs will be sent to the outputs after a time out of 10 seconds.

The Override option is very useful when sailing alternately with our without a laptop or tablet. Consider a typical set-up as shown in Figure 35:




Figure 35

When the tablet is connected, it will receive all information from the instruments and the navigation software calculates the course to steer and drives the autopilot accordingly. Because the tablet is sending NMEA data, the multiplexer routes this data exclusively to Out1. The autopilot will therefore receive information from the tablet only.

When the tablet is not connected or the navigation software is not sending any data, the multiplexer automatically routes the inputs to Out1, sending the data from the instruments to the autopilot. This way, the autopilot will receive course information directly from the GPS.

Options

On the Options page several options and conversions can be chosen.




Figure 36

Priority

This option deletes duplicate NMEA sentences received on multiple inputs. When enabled, the multiplexer assigns a priority to incoming NMEA data based on the input on which it is received. The host interfaces have the highest priority, followed by NMEA In1, In2, In3 and In4 in descending order. NMEA conversion results have the same priority as the input that received the source of the conversion.

If for instance two GPS receivers are connected to In1 and In2 and both GPS receivers send GPRMC sentences, only those from the GPS on In1 are passed. This feature can be useful to set up a second GPS as a backup for the main GPS.

The multiplexer only uses the Sentence Formatter (the RMC part) for comparison - the Talker ID (the GP part) is ignored.

Another useful application of Priority is when a GPS and an AIS transponder are connected to the multiplexer. An AIS transponder often sends sentences from its internal GPS. A navigation program will now receive GPS data from two sources that might differ in position due to GPS inaccuracy. This will lead to navigation errors. When the AIS transponder is connected to In1 and the GPS to In2, all the NMEA sentences from the AIS transponder is passed while duplicate NMEA sentences (e.g. GPRMC) from the GPS are blocked. When the AIS transponder fails, GPRMC sentences from the GPS will be passed again after an adjustable timeout.

Note that the priority system does not block an entire input, it only blocks duplicate sentences. Sentences received from the GPS that are not received on the AIS input are passed.

The following example shows what is passed and what not: the left column in Table 1 shows sentences from the AIS transponder on In1 and the right column sentences from the GPS on In2. The greyed sentence in the table is blocked by the priority system.

AIS (In1)	GPS (In2)
GPRMC	GPRMC
AIVDM	GPGGA

Table 1

The priority feature can store up to 50 different sentence types to determine their priority. A time out mechanism ensures that sentences received on lower priority inputs are passed again after an adjustable time out when their duplicates on higher priority inputs are no longer received.

Check GPS status

Normally, the priority system detects the *absence* of NMEA sentences. With "Check GPS status" enabled, it detects *invalid* sentences, specifically from a GPS.

When a secondary GPS is connected as a backup to the primary GPS, the primary GPS must completely fail (stop sending data) before sentences from the secondary GPS are passed. In a situation where the primary GPS no longer receives any signal from satellites (broken antenna, cable etc.), it will still send NMEA sentences to the multiplexer. Thus the priority system will not fall back to the secondary GPS. When "Check GPS status" is enabled, the multiplexer checks the status field of GPS sentences. When the status field indicates "Invalid data", the multiplexer will block these sentences, allowing the priority system to time out and pass sentences from the secondary GPS. Sentences of which the Status flag is checked are APB, GGA, GLL, RMA, RMB, RMC, VTG and XTE.

Time Out

This setting allows you to set the time it takes before sentences from a lower priority input are passed.

SeaTalk Priority

This sets the priority of the SeaTalk data. It can be either Highest (SeaTalk - In1 - In2 - In3) or Lowest (In1 - In2 - In3 - SeaTalk).

Channel Information

These options insert channel number information in the NMEA stream that is sent to the host interfaces. Channel numbers allow distinguishing between similar data from different instruments, like two depth sounders on the same boat.

When "STN Sentence" is enabled, each received NMEA sentence is preceded by a \$MXSTN sentence to indicate on which NMEA input the following sentence was received. The example in Figure 37 shows that an IIGGA sentence was received on In1, a GPGGA sentence on In2, an IIGLL sentence on In1 and an HEHDT sentence on In3.

```
$MXSTN,01*71
$IIGGA,143357.999,5301.0061,N,00635.5479,E,1,06,1.9,90.0,M,,,,0000*2E
$MXSTN,02*72
$GPGGA,143357.999,5301.0061,N,00635.5479,E,1,06,1.9,90.0,M,,,,0000*39
$MXSTN,01*71
$IIGLL,5301.0061,N,00635.5479,E,143357.999,A*22
$MXSTN,03*73
$HEHDT,67.0,T*1E
```

Figure 37

The \$MXSTN sentence is defined by the NMEA standard and a description can be found in the Technical Reference at the back of this manual.

When "TAG Block" is enabled, the multiplexer adds an NMEA 0183 V4.0 TAG block to each sentence. This TAG block contains a source identification parameter indicating on which input that sentence was received. Figure 38 shows the same data as above, but with TAG blocks added.

```
\s:MX02-1*42\IIGGA,143357.999,5301.0061,N,00635.5479,E,1,06,1.9,90.0,M,,,,0000*2E
\s:MX02-2*41\GPGGA,143357.999,5301.0061,N,00635.5479,E,1,06,1.9,90.0,M,,,,0000*39
\s:MX02-1*42\IIGLL,5301.0061,N,00635.5479,E,143357.999,A*22
\s:MX02-3*40\HEHDT,67.0,T*1E
```

Figure 38

See the Technical Reference section for a description of the TAG block.

NMEA Conversions.

NMEA Conversions allow you to convert specific NMEA sentences into new NMEA sentences. The originating sentence used for a conversion is forwarded as usual but if desired, it can be blocked using the sentence filter. The conversion results are available on a virtual input called "NMEA Conversions" on the "NMEA Inputs/Outputs" page and on input C on the "Sentence Filtering & Routing" page. They can be routed anywhere using the default route and the Sentence Filter.

Magnetic to True Heading (HDG, HDM -> HDT)

If this option is enabled, the multiplexer will generate an HDT sentence (true heading) when an HDG or HDM sentence (magnetic heading) is received. If the originating HDG sentence contains a magnetic variation, it is used to calculate the true heading from the magnetic heading. Otherwise the magnetic heading value is just copied.

This option can be useful when a device needs a true heading while only a fluxgate compass is available on board. Many satellite telephones for instance need a true heading to be able to direct their antenna to the right communications satellite.

GPS Speed to Log Speed (VTG -> VHW)

If this option is enabled, the multiplexer will generate a VHW sentence (water speed and heading) when a VTG sentence (course over ground and ground speed) is received. The VTG sentence is generated by a GPS and the VHW sentence by a log. Often the paddlewheel of a log gets stuck when fouled and this option offers a solution to substitute the log data with GPS data.

Reverse Heading (HDT)

This option allows you to reverse the true heading in a received HDT sentence. When an HDT sentence is received, the multiplexer generates a new HDT sentence with 180° added to the original heading. This

can be used to provide two opposing navigation stations on ferries with a heading from the same gyrocompass. Use the default route or Sentence Filter to route each sentence to a different NMEA output and only one to the host if needed.

Sentence Filtering & Routing

The Sentence Filtering & Routing feature is the most powerful feature of the MiniPlex. It allows you to filter and route NMEA sentences based on the Address Field of an NMEA sentence (the GPRMC part) and optionally reduce the rate of the sentence. Sentences can be passed or blocked, specified by input (filtering) and they can be forwarded to specific outputs (routing). Up to 50 rules can be entered, either manually or by capturing the NMEA sentences received by the multiplexer.




Figure 39

Each filter/routing rule in the list consists of the Address Field of an NMEA sentence, checkboxes to specify the source inputs and destination outputs and a divisor factor to reduce the sentence rate. The buttons on the right allow you to modify the list and to store it into the multiplexer.

Editing the list

It is important to keep in mind that all modifications and additions are made to the list loaded in MPX-Config. The current list is automatically loaded from the multiplexer when you connect to the multiplexer or when you click on the "Read Configuration" button. After editing, the list must be stored in the multiplexer to be effective.

The Filter & Routing list contains the following columns:

Inputs:

- H: This input represents the combined input from the host interfaces.
- 1-4: NMEA inputs 1 to 4.
- C: NMEA Conversion results.

Sentence: The Address Field of an NMEA sentence. This fully specifies the type of NMEA sentence to be filtered/routed. A '-' (dash) matches any character. If for instance --GLL is entered, any sentence that ends on GLL will match, regardless of the first two characters (the Talker ID). A P---- will match on every proprietary sentence starting with \$P. The Sentence field must contain 5 characters

Div: Divisor field. A number from 0 to 99 will divide the sentence rate by the number entered. If this field contains a divisor of 5 for instance, every fifth occurrence of this sentence will be passed.

Outputs:

- 1,2: NMEA outputs 1 and 2.
- PC: The wired host connection of the multiplexer (RS-232, USB, Ethernet).
- W: The wireless host connection of the multiplexer (WiFi, Bluetooth).

Clicking on a checkbox changes its state from checked to unchecked and vice versa. This determines whether a sentence is passed (checked) or blocked (unchecked). The Sentence and Divisor fields can be edited by selecting it with the cursor. Edit mode is entered in several ways:

- Press function key F2 on your keyboard. This enters Edit mode with the cursor at the end of the text. Move the cursor around with the mouse or arrow keys.

- Press Enter or click with the cursor: This enters Edit mode with the text selected and the cursor at the end. Any character or number that is typed now will erase the existing text entirely unless the cursor is moved around with the mouse or arrow keys. This will unselect the text.
- Double-click on the entry. This enters Edit mode the same way as pressing Enter or clicking it for the second time.

When changes are made, press Enter to confirm them or press Escape to discard any changes and exit Edit mode.

The Technical Reference section lists commonly used Talker IDs and Sentence Formatters. This list can be a useful aid while setting up the sentence filter.

The following buttons are available to edit the list:

Store List	Stores the list from MPX-Config into the multiplexer. This overwrites the list in the multiplexer.
Capture	Enables capture mode. The list will be filled automatically with NMEA sentences that are received by the multiplexer.
Add	Add a new rule. Type the desired sentence address into the edit box next to the Add button and click on Add or press the enter key. This will enter a new rule with all inputs disabled and all outputs enabled. The input is case-insensitive; every entered sentence address will be converted into uppercase. The input must contain 5 characters, including dashes. Numbers are also allowed.
Delete	Delete a rule from the list in MPX-Config. Select the entry to be deleted by clicking on the address in the Sentence column (--GLL in the example) and click on the Delete button.
Default Action	This determines what happens when a received sentence is not found in the filter/routing list. It can be set to pass or block such a sentence.
Clear List	This button clears the list in MPX-Config (not in the multiplexer!). To clear the list in the multiplexer, click on the Store button after clearing the list in MPX-Config.

Filling the list

The filter rules can be entered in two ways: manually and automatically. You can add individual sentences to the list and set the desired routing information. You can also fill the list automatically with the Capture button. All controls will be disabled during capture and the Capture button changes to Stop. Leave the capture mode running for approximately 10 seconds. By that time, all connected instruments will have sent NMEA sentences. Click on Stop to end the capture mode.

It is very important to realize that using capture to fill the list overrides the default routes since every sentence is in the filter list. It is therefore absolutely necessary to review and modify the routing settings for each sentence to prevent massive buffer overflows! It is often best not to use the filter at all if you don't need sentence-specific routing.

Use the filter with care! Simply capturing the list and storing it unmodified is useless and can lead to unforeseen problems!

Operation

When the multiplexer receives an NMEA sentence, it searches the filter list for a match. The order of filter rules in the multiplexer is exactly the same as shown in MPX-Config. When a match is found, the input on which the sentence was received is checked against the input settings in this rule to determine whether the sentence may be passed or not. If the input matches, the sentence is routed to the outputs that are enabled.

If no match is found, the "Default Action" determines what happens next: when set to Pass, the default routes are applied. When it is set to Block, the sentence is always blocked.

The default routes are set in the "Input Settings" section on the "NMEA Inputs/Outputs" page. Note that the multiplexer will not pass any sentence when the filter list is empty and the "Default Action" is set to Block.

It is important to know that when a Talker ID is set for an input, it is applied to incoming NMEA sentences before the sentence filter processes them. A filter rule must therefore contain the correct Talker ID.

Example

Figure 40 shows a small set of filter rules:

	Inputs						Sentence	Div	Outputs			
	H	1	2	3	4	C			1	2	PC	W
1		✓					GPRMC	0	✓		✓	
2			✓				HCHDT	5			✓	
3				✓			IIMWV	0			✓	
4				✓			IIMTW	0			✓	
5						✓	VHVHW	0	✓		✓	

Figure 40

These rules have the following effect:

- GPRMC sentences are passed only when received on input 1 and they are routed to output 1 and to the PC.
- HCHDT sentences are passed from input 2 and routed to the PC. Only every 5th sentence is passed.
- IIMWV and IIMTW sentences are passed from input 3 and routed to the PC.
- VHVHW sentences are passed only as the result from a conversion (VTG -> VHW) and thus passed from input C to output 1 and the PC.

None of the sentences are sent to the wireless interface (W) and the default route is applied on sentences that are not in the filter list.

Firmware Update

From time to time, we will develop new features for the multiplexer or fix bugs in the existing firmware. New firmware image files will then be made available through our website. These image files can be downloaded to your computer and loaded into the multiplexer with the option "Update MiniPlex Firmware..." from the File menu.

The MiniPlex needs to be connected to your computer using a wired host port such as RS-232, USB or Ethernet. **Updating via a wireless connection (WiFi or Bluetooth) is not possible.**

If you are using an RS-232 connection, you must set the communication speed to 38400 Baud.

Choose "Update MiniPlex Firmware..." from the File menu.

A file dialog opens which allows you to select the previously downloaded image file ending at an ".mpx" extension. When you have selected the file and clicked on OK, the update process is started. The image file's integrity and version is checked first before initiating the download procedure in the multiplexer.

When the download is started, the red LED on the multiplexer will be lit continuously while the green LED blinks on reception of data from the computer. MPX-Config will show a progress indicator during the update process. When the update is complete and successful, a message will show "The firmware update was successful".

Any errors that occur during the process will be shown. It is important to make a note of the error message when asking for support. See "Firmware Update Error messages" for an explanation of the error messages.

Sometimes the communication during the firmware update times out and the update is aborted with an error message. This time out is caused by delays in the communication drivers that are part of Windows. These time outs happen frequently when software is running which communicates with other serial devices.

When such a time out occurs, the MiniPlex has no firmware loaded and the internal loader keeps sending \$PSMDLDR... sentences, indicating that it waits for a firmware upload. Just try updating again until the process is successful. Sometimes it helps to try the update on a different computer.

WiFi Firmware Update

The MiniPlex-2Wi has a WiFi interface module, which contains its own firmware. This firmware is created by the manufacturer of the WiFi module and from time to time a new version with new features or bug fixes is released. These updates are available on the download page of our web site.

Sometimes new WiFi firmware also requires new MiniPlex firmware. If this is the case, it will be clearly mentioned in a ReadMe.pdf file that comes with the WiFi firmware package. It is important to update the MiniPlex firmware first, before updating the WiFi firmware.

The MiniPlex firmware version number is displayed on the status bar at the bottom of the MPX-Config window. The WiFi firmware version number can be obtained by entering the following command in "Manual NMEA Sentence Input":

```
PSMDWI,V
```

The following response will be visible in the NMEA viewer:

```
$PSMDWI,VER,x.xx
```

where x.xx represents the WiFi firmware version number.

If navigation data is visible in the NMEA viewer, its best to either shut down the all sources of NMEA data into the MiniPlex or to temporary set the speed of the NMEA inputs of the MiniPlex to non-standard values. This will effectively mute the inputs and ensures that all messages during the firmware update are visible.

Preparation

In order to successfully update the WiFi firmware, a few preparations must be made:

1. The latest MPX-Config version must be installed.
2. A working USB connection must exist from your computer to the MiniPlex. The update process uses both the USB connection and the WiFi connection
3. All WiFi devices like tablets and phones that are connected to the WiFi network of the MiniPlex must be **shut down** or at least have the WiFi connection disabled. A tablet or phone that is in stand-by mode may still occasionally connect to the WiFi network!
4. The zip file containing the firmware files must be unpacked into a folder on your computer.

Windows Firewall

The WiFi firmware is updated using the WiFi connection. MPX-Config instructs the MiniPlex through the USB interface to download the WiFi firmware **via WiFi** from a server that is built-in in MPX-Config.

Usually the Windows Firewall will block this download. When you initiate the update process, Windows might show you a Security Alert message as shown in Figure 41. Click on "Allow Access" to proceed.

If you wait too long, the update process might time out and abort. This is no problem - just start the update again.




Figure 41

Procedure

1. Start MPX-Config and connect via USB.
2. From the File menu choose "Update MiniPlex Firmware..." and select the "miniplex-2_x.xx.mpx" file to start the MiniPlex firmware update. Wait until the update is completed.
3. From the Tools menu choose "Reset Factory Settings..."

4. Enter the following command in Manual NMEA Sentence Input: `PSMDWI,A`
This resets the WiFi module to factory settings. The following message should appear in the NMEA viewer:

```
$PSMDWI,Initializing WiFi interface...
$PSMDWI,RDY
```

5. Now setup your computer to connect to the WiFi network of the MiniPlex. If you are unable to connect, make sure no other device is still connected. You may need to temporarily disable the WiFi connection on your iPad or iPhone. Even if these devices are in stand-by, they can maintain a WiFi connection to the MiniPlex, which prevents your computer to connect.
6. Verify the WiFi connection by using MPX-Config to connect via TCP at address 10.0.0.1. If the connection is successful, the WiFi connection is working
7. Select USB again and connect. Now you are ready to perform the WiFi update.
8. From the File menu choose "Update WiFi Firmware..." and select the "wifi-ap_x.xx.img" file to start the WiFi firmware update.

The following messages should now appear in the NMEA viewer:

```
$PSMDWI,Initiating WiFi firmware update
$PSMDWC,connecting to xxx.xxx.x.xxx
$PSMDWC,FTP file=xx
$PSMDWC,.....
$PSMDWC,.....
$PSMDWC,FTP OK.
$PSMDWC,UPDATE OK
$PSMDWC,Resetting WiFi interface...
$PSMDWI,Initializing WiFi interface...
$PSMDWI,RDY
```

See paragraph "WiFi Update Messages" for an explanation of these messages.

In some cases, a `$PSMDWC,No response` message appears after the last WiFi initialization message. This means that the update was successful but the reconfiguration of the WiFi module was not. If this is case, enter the following two commands in "Manual NMEA Sentence Input":

```
PSMDRESET
PSMDWI,A
```

After the last command, the following messages should appear:

```
$PSMDWI,Initializing WiFi interface...
$PSMDWI,RDY
```

The update is now completed.

Mounting

The multiplexer is not waterproof. It should be mounted at a dry place such as behind the instrument panel on a flat surface.

Technical Reference

NMEA Glossary

This glossary lists the most common Talker ID's and Sentence Formatters in alphabetical order.

Talker ID's

AG	Autopilot (general)
AP	Autopilot (magnetic)
AI	Automatic Identification System
CD	Communications: Digital Selective Calling (DSC)
CR	Data receiver
CS	Satellite
CT	Radio telephone (MF/HF)
CV	Radio telephone (VHF)
CX	Scanning receiver
DE	Decca navigator
DF	Direction finder
EC	Electronic chart systems (ECS)
EI	Electronic chart display and information system (ECDIS)
EP	Emergency position indicating radio beacon (EPIRB)
ER	Engine room monitoring systems
GP	Global Positioning System (GPS)
GL	GLONASS receiver
GN	Global navigation satellite system (GNSS)
HC	Heading sensors: compass, magnetic
HE	gyro, north seeking
HN	gyro, non-north seeking
II	Integrated instrumentation
IN	Integrated navigation
LC	Loran, Loran-C
P	Proprietary sentence
RA	Radar and/or radar plotting
SD	Sounder, depth
SN	Electronic positioning system, other/general
SS	Sounder, scanning
TI	Turn rate indicator
VD	Velocity sensors: doppler, other/general
VM	speed log, water, magnetic
VW	speed log, water, mechanical
VR	Voyage data recorder
YX	Transducer
ZA	Timekeepers: atomic clock
ZC	chronometer
ZQ	quartz
ZV	radio updated
WI	Weather instruments

Sentence formatters

AAM	Waypoint arrival alarm
ACK	Acknowledgement alarm
ALM	GPS almanac data
ALR	Set alarm state
APB	Heading/track controller (Autopilot) sentence B
BEC	Bearing and distance to waypoint, dead reckoning
BOD	Bearing, origin to destination
BWC	Bearing and distance to waypoint
BWR	Bearing and distance to waypoint, rhumb line
BWW	Bearing, waypoint to waypoint
DBT	Depth below transducer
DCN	DECCA position
DPT	Depth
DSC	Digital selective calling information
DSE	Expanded digital selective calling
DSI	DSC transponder initialise

DSR	DSC transponder response
DTM	Datum reference
FSI	Frequency set information
GBS	GNSS Satellite fault detection
GGA	Global positioning system fix data
GLC	Geographic position, LORAN-C
GLL	Geographic position, latitude/longitude
GNS	GNSS fix data
GRS	GNSS range residuals
GSA	GNSS DOP and active satellites
GST	GNSS pseudo range error statistics
GSV	GNSS satellites in view
HDG	Heading, deviation and variation
HDT	Heading, true
HMR	Heading monitor – receive
HMS	Heading monitor – set
HSC	Heading steering command
HTC	Heading/track control command
HTD	Heading/track control data
LCD	LORAN-C signal data
MLA	Glonass almanac data
MSK	MSK receiver interface
MSS	MSK receiver signal status
MTW	Water temperature
MWD	Wind direction and speed
MWV	Wind speed and angle
OSD	Own ship data
RMA	Recommended minimum specific LORAN-C data
RMB	Recommended minimum navigation information
RMC	Recommended minimum specific GNSS data
ROT	Rate of turn
RPM	Revolutions
RSA	Rudder sensor angle
RSD	Radar system data
RTE	Routes
SFI	Scanning frequency information
STN	Multiple data ID
TLB	Target label
TLL	Target latitude and longitude
TTM	Tracked target message
TXT	Text transmission
VBW	Dual ground/water speed
VDR	Set and drift
VHW	Water speed and heading
VLW	Distance travelled through the water
VPW	Speed, measured parallel to wind
VTG	Course over ground and ground speed
WCV	Waypoint closure velocity
WNC	Distance, waypoint to waypoint
WPL	Waypoint location
XDR	Transducer measurements
XTE	Cross-track error, measured
XTR	Cross-track error, dead reckoning
ZDA	Time and date
ZDL	Time and distance to variable point
ZFO	UTC and time from origin waypoint
ZTG	UTC and time to destination waypoint

Translated SeaTalk datagrams

When the SeaTalk translation is enabled, the following datagrams are translated into NMEA sentences:

SeaTalk	NMEA	Description
00	DBT	Depth below transducer
10	MWV	Wind angle, (10 and 11 combined)
11	MWV	Wind speed, (10 and 11 combined)
20	VHW	Speed through water, includes heading when present
21	VLW	Trip mileage (21 and 22 combined)
22	VLW	Total mileage (21 and 22 combined)
23	MTW	Water temperature
25	VLW	Total and Trip mileage
26	VHW	Speed through water, includes heading when present
27	MTW	Water temperature
50	---	GPS latitude, value stored
51	---	GPS longitude, value stored
52	---	GPS speed over ground, value stored
53	RMC	Course over ground. RMC sentence is generated from stored values from other GPS related datagrams.
54	---	GPS time, value stored
56	---	GPS date, value stored
58	---	GPS lat/long, values stored
89	HDG	Magnetic heading, including variation (99)
99	---	Magnetic variation, value stored

The table shows that not all datagrams result in an NMEA sentence. Some datagrams are only used to retrieve data, which is combined with data from other datagrams to be able to create one NMEA sentence.

When the SeaTalk translation is enabled with option 2 (the s parameter in the CF sentence is 2), unlisted datagrams are translated into a proprietary NMEA sentence with the following format:

```
$PSMDST,aa,bb,cc,dd...*hh<CR><LF>
```

aa,bb,cc,dd... represent the hexadecimal value of the bytes from the received SeaTalk datagram.

Firmware Update Error messages

During a firmware update, the following warnings or error messages may be displayed:

The firmware update failed

This message appears when the overall update process failed without any other error message. It is shown when the updated multiplexer firmware does not report a version message after start-up.

Not a valid firmware file

The file you are trying to open is not a valid firmware file. A firmware file not only ends with an ".mpx" extension, it also contains a distinct signature that must be present. This prevents you from accidentally loading the wrong file into the multiplexer.

Unsupported firmware file version

The firmware file version is not supported by MPX-Config. Currently, there is only one firmware file version but it is not unlikely that in the future new versions are developed which require an update of MPX-Config.

Firmware file is corrupt

The firmware file is damaged, possibly due to an error during download from our website.

The version of the firmware file is lower than the version of the multiplexer. Do you really want to proceed?

You are trying to update the firmware in the multiplexer with an older version. This is just a warning and very well possible to do.

Bootloader initialisation failed

When MPX-Config starts the update process, a small program called the Bootloader must be started in the multiplexer. This message tells you that the bootloader could not be started. This can happen when you try to update the multiplexer while navigation instruments are connected and sending lots of NMEA data to the multiplexer. This can interfere with starting the update process. Disconnect or power down the instruments to prevent this problem.

Firmware file does not match with the multiplexer type

Most firmware files will be compatible with all types of multiplexers. It is however possible that special firmware is made available which only runs on a specific type of multiplexer. If this message appears, you apparently are trying to update using a firmware file that is not suitable for your type of multiplexer.

Bootloader: Erase command timeout

An error occurred when the bootloader tried to erase the old firmware.

Bootloader: Encryption command timeout

The bootloader did not respond to the Encryption command sent by MPX-Config.

Bootloader: Programming timeout

There was an error during programming a section of the firmware image.

Bootloader: CRC command timeout

The bootloader failed to calculate the checksum of the newly loaded firmware image.

Bootloader: CRC error

The calculated checksum of the newly loaded firmware image does not match the checksum of the image file. Apparently there was a communication error between MPX-Config and the multiplexer. You can try to update again.

Invalid response from bootloader

The bootloader returned an unknown response to a command from MPX-Config.

WiFi Update Messages

The following is an explanation of the messages shown during the WiFi firmware update.

\$PSMDWC,connecting to xxx.xxx.x.xxx

The FTP client in the WiFi module connects to the FTP server in MPX-Config. The IP address shown is the address of your computer. When this connection fails, a time out message may occur like
\$PSMDWC,Timeout=2

\$PSMDWC,FTP file=xx

The FTP client downloads the firmware file and stores it into its own file system where xx is the number of the file. This indicates a successful start of the download.

\$PSMDWC,.....

This is a progress indicator showing the actual file transfer takes place

\$PSMDWC,FTP OK.

This message tells us that the file transfer was successful.

\$PSMDWC,UPDATE OK

This message indicates that the firmware was updated successfully.

Proprietary NMEA Sentences

The MiniPlex multiplexers are configured with proprietary NMEA sentences that can be sent to the multiplexer through the host interface.

The multiplexer can also output proprietary NMEA sentences on a host interface to output status information or a response to a received proprietary NMEA sentence.

The multiplexer also outputs some standard NMEA sentences. These sentences all start with 'MX', which is the talker ID for a multiplexer as defined by the NMEA standard.

All MiniPlex proprietary sentences have the following format:

`$PSMDxx[,a,b,...][*hh]<CR><LF>`

`$P`: Start of a proprietary command as dictated by the NMEA standard
`SMD`: ShipModul manufacturer mnemonic
`xx`: Two- or three-character sentence formatter
`a,b,...`: Optional fields
`hh`: Optional checksum
`<CR><LF>`: Carriage Return and Line Feed characters that terminate the sentence

Unless specified otherwise, fields are optional (except the Sentence Status field) and may be skipped when no change is required. For instance, a `$PSMDCF,C,,,,1` sentence only enables Channel Numbers. The preceding fields are skipped (`,,,,`) and the trailing fields are omitted.

For ease of manual configuration, these sentences do not require a checksum. If the sentence has a checksum however, it is checked and the sentence is rejected when a checksum failure occurs. Sentences output by the multiplexer always contain a checksum unless the checksum check is switched off. Checksums are denoted with `*hh` in the descriptions below.

Unless specified otherwise, all command sentences return a status report of their settings when sent without parameters.

Thus a `$PSMDCF` sentence will return `$PSMDCF,R,b,s,p,n,rrrrr,h,v,t,f,r*hh<CR><LF>`

Most sentences have a Sentence Status field that indicates whether the sentence is a status report or a command. The first field of the sentence contains an 'R' when the sentence is a status report as a result of a sentence without any parameters. The first field contains a 'C' when the sentence is a command to the multiplexer.

A sentence with its Status Field set to 'R' is ignored by the multiplexer.

Example

When a `$PSMDID` sentence is sent to the multiplexer, it will respond with `$PSMDID,R,aa,bb,cc,dd,ee*hh`

To send this sentence as a command to the multiplexer, `$PSMDID,C,aa,bb,cc,dd,ee` should be sent.

`$PSMDCF` – Set Configuration

This sentence sets various configuration settings of the multiplexer.

Format: `$PSMDCF,a,b,rrrrr,t*hh<CR><LF>`

`a`: Sentence Status flag:
R = sentence is a status report of current settings
C = sentence is a command to change settings

`b`: Baudrate selector for the RS-232 interface (ignored when no RS-232 port present):
0 = 4800 Baud
1 = 9600 Baud
2 = 19200 Baud
3 = 38400 Baud
4 = 57600 Baud
5 = 115200 Baud

`rrrrr`: Real-time mode:
0 = off
1 = on
Five digits, one digit per input, 1 to 5 from left to right. Input 5 is the source of internally generated sentences from NMEA conversions.

t: Priority Timeout (in seconds):
 0 = 1
 1 = 2
 2 = 3
 3 = 5
 4 = 10
 5 = 30

The 's' field will always return a 0 or 1 in response to a CF query sentence.

\$PSMDDR – Set Default Route

This sentence specifies the default route from the NMEA inputs to the NMEA outputs and from the host interface to the NMEA outputs. Any route set by the FL sentence overrides the standard route.

Format: \$PSMDDR,a,xxxxx,b,yyyyy,c*hh<CR><LF>

a: Sentence Status flag:
 R = sentence is a status report of current settings
 C = sentence is a command to change settings

xxxxx: Input field for NMEA Out1. Each 'x' represents an input, numbered from 1 to 5 from left to right. Input 5 is not a real input but the source of NMEA sentences generated from conversions. When '1', the input is routed to output 1. When '0', the input is not routed to output 1.

b: Host data to NMEA Out1:
 0: Host data is not routed
 1: Host data is routed
 2: Host data is routed and overrides data from the inputs. A time out mechanism will route data from the inputs when no data from the host is received.

yyyyy: Input field for NMEA Out2. Each 'y' represents an input, numbered from 1 to 4 from left to right. Input 5 is not a real input but the source of NMEA sentences generated from conversions. When '1', the input is routed to output 2. When '0', the input is not routed to output 2.

c: Host data to NMEA Out2:
 0: Host data is not routed
 1: Host data is routed
 2: Host data is routed and overrides data from the inputs. A time out mechanism will route data from the inputs when no data from the host is received.

\$PSMDFL – Set Filter Rules

This sentence specifies a filter and routing rule that is applied on every incoming NMEA sentence. Filter rules are specified using the address field of an NMEA sentence. For each filter rule, the inputs on which the sentence may be received must be specified. Optionally, a divisor and an output routing field can be added.

Sentences for which no rule exists are passed or blocked, depending on the filter mode set by field 'f' of the CF sentence.

Format: \$PSMDFL,a,ccccc,xxxxxx,dd,yyyy*hh<CR><LF>

a: Sentence Status flag:
 R = sentence is a status report of current settings
 C = sentence is a command to change settings

ccccc: Address field of the filter rule (e.g. 'GPRMC', 'IIMWV', etc). This field may contain wildcard characters ('-'). For instance, 'GP---' will apply to all sentences starting with 'GP'. Similarly, '-M WV' will apply to all sentences ending on 'M WV' regardless of the Talker ID. One filter rule with all wildcards and all inputs blocked is allowed to let the multiplexer block all sentences for which no rule exists. When an all-wildcard rule is entered, the multiplexer will not accept subsequent filter rules.
 Example: \$PSMDFL,-----,00000<CR><LF>

xxxxxx: Input field. Each 'x' represents an input to assign to this rule, numbered from 0 to 5 from left to right. Input 0 is the host interface and inputs 1 to 4 represent NMEA inputs 1 to 4. Input 5 is not a real input but the source of NMEA sentences generated from conversions. A '1' means that the sentence must be forwarded while a '0' means that the sentence must be blocked from that input.

- dd: Optional divisor factor (0..99). The rate or frequency of a sentence is divided by this number to reduce the number of sentences over time. If for instance a divisor of 6 is specified, only every 6th occurrence of this sentence is passed.
- yyyy: Optional routing field. Each 'y' represents an output the NMEA sentence must be routed to. A '1' routes the sentence to an output, a '0' does not. Each digit represents one output. From left to right, the outputs are NMEA Out1, NMEA Out2, Host and Wireless interface. When this field is omitted, a default of '1111' is assumed, routing the specified sentence to all outputs.
- hh: Optional checksum

An FL sentence with the word DELETE in the 'cccc' field erases all rules. An FL sentence with only a 'cccc' field will erase that entry. The filter accepts duplicate entries with the same 'cccc' field to allow separate routes from inputs to outputs.

Example: \$PSMDFL,C,HEHDT,000110,5,1010<CR><LF>

This sentence specifies a rule for all sentences that have 'HEHDT' in the address field. It only passes HEHDT sentences from inputs 3 and 4, the rate is lowered by a factor of 5 and the sentence is routed to NMEA Out1 and the host only.

When the filter list is requested, the multiplexer responds by sending FL sentences, one for each list entry. An empty FL sentence marks the end of the list.

Example response:

```
$PSMDFL,R,GPRMC,100110,0,1111*4A<CR><LF>
$PSMDFL,R,GPGGA,100010,0,1111*56<CR><LF>
$PSMDFL,R,--VWT,010000,5,0001*50<CR><LF>
$PSMDFL,R,GPGSV,000010,0,0010*55<CR><LF>
$PSMDFL,R*2C<CR><LF>
```

The sentences may not be dumped as one contiguous block. In case of much NMEA data, they may be interspersed with other NMEA sentences.

\$PSMDID – Set Talker ID

This sentence sets a Talker ID translation for a specific input. If a Talker ID is specified, the original Talker ID of the sentences received on that input is replaced by the specified one, before sending the sentence to the host.

Format: \$PSMDID,a,aa,bb,cc,dd,ee*hh<CR><LF>

- a: Sentence Status flag:
R = sentence is a status report of current settings
C = sentence is a command to change settings
- aa: Talker ID for channel 1
bb: Talker ID for channel 2
cc: Talker ID for channel 3
dd: Talker ID for channel 4
ee: Talker ID for internally generated sentences
hh: optional checksum

An empty field clears the ID and disables the translation for that specific channel.

\$PSMDIN – Input options

Set the operating mode of an NMEA input.

Format: \$PSMDIN,a,x,x,x,x

- a: Sentence Status flag:
R = sentence is a status report of current settings
C = sentence is a command to change settings
- x: Operating mode field for input 1 to 4:
0: Normal NMEA processing.
1: Pass NMEA sentences containing an erroneous checksum unmodified, bypassing all further NMEA processing.

- 2: Relaxed NMEA format checking. Normally the multiplexer only passes sentences when they are correctly formatted: starting with a '\$' or a '!' and ending on a CR/LF pair. When this mode is selected, an NMEA sentence will be passed if it starts with a '\$' or a '!' and ends on a CR or a LF or a combination of both in arbitrary order. A sentence with a checksum error is blocked.
- 3: Accept plain text strings as input and forward them in \$MXTXT sentences. Any character with an ASCII value > 32 (a space) is considered to be the start of a string. The string must end on a CR or LF and may not be longer than 61 characters. A longer string is discarded. Only valid NMEA characters are passed. Invalid characters are stripped from the input data. The Total number and Sentence number fields are always set to '01'. The Text Identifier field of the \$MXTXT sentence contains the input number on which the text was received. When for instance 'Hello World' is received on input 3, the resulting sentence will be:
\$MXTXT,01,01,03,Hello World*6E
- 4: Accept plain text strings as input and forward them in \$PTXT sentences. Any character with an ASCII value > 32 (a space) is considered to be the start of a string. The string must end on a CR or LF and may not be longer than 61 characters. A longer string is discarded. The multiplexer will always end a forwarded string with a CR/LF pair. All characters with an ASCII value from 32 to 127 are passed.
- 5: Accept plain text strings as input and forward them as plain text. Any character with an ASCII value > 32 (a space) is considered to be the start of a string. The string must end on a CR or LF and may not be longer than 61 characters. A longer string is discarded. The multiplexer will always end a forwarded string with a CR/LF pair. All characters between from ASCII 32 to 127 are passed.
- 6: SeaTalk to NMEA conversion on input 4 only. When this mode is selected, the \$PSMDOP response will show option 3 enabled. Any other mode (0..4) will clear both SeaTalk options in the \$PSMDOP response.

\$PSMDLDR – Loader message

This sentence is output by the bootloader on the host interface. It contains the loader version and multiplexer ID. The loader will wait for a special key during 0.2s after sending this sentence. When no key is received, the multiplexer application code is started. If no application code is found, the loader will continue sending this sentence.

Format: \$PSMDLDR,xx,v.v,zzz

xx: Hardware ID of the multiplexer (a hexadecimal number)

v.v: Bootloader version number

zzz: Hardware name of the multiplexer

The following hardware ID's and names are defined:

01: MPX-S (board with RS-232 interface)

02: MPX-U (board with USB interface)

03: MPX-E (board with Ethernet interface)

04: MPX-W (board with USB and WiFi interface)

When bit 7 of the hardware ID is set, e.g. 81, the board has a Bluetooth module installed.

Example: \$PSMDLDR,82,1.2,MPX-U

This multiplexer has a MPX-U board with a USB interface and a Bluetooth module installed and the bootloader is version 1.2.

\$PSMDOP – Set Options

This sentence is used to enable or disable various options.

Format: \$PSMDOP,a,o,e*hh<CR><LF>

or: \$PSMDOP,a,xxxxxxxx*hh<CR><LF>

a: Sentence Status flag:
R = sentence is a status report of current settings
C = sentence is a command to change settings

o: option number

e: 0 = off/disable

1 = on/enable

xxxxxxx: all options at once as a 32 bit hexadecimal number. Each bit represents an option where bit 0 is option 0, bit 1 is option 1 etc.

Example: \$PSMDOP,C,6,1<CR><LF> (enables option 6)
\$PSMDOP,C,00000021<CR><LF> (enables options 5 and 0)

The following options are defined:

0: Enable Priority

1: Enable highest priority for SeaTalk data. Only effective when Priority and SeaTalk translation are enabled.

2: Test GPS status field for priority check. When enabled, the status field of a GPS related sentence is checked. When the data is invalid, the sentence is discarded to allow the Priority mechanism to pass GPS data from a lower priority input.

3: Enable SeaTalk to NMEA translation. This will also be reflected in the \$PSMDIN response: input 5 will report SeaTalk mode.

4: Convert SeaTalk datagrams into \$PSMDST,xx,xx,... sentences. Datagrams are only converted if they are not translated into NMEA. When option 3 is enabled, only unknown datagrams are converted, otherwise all datagrams are converted. . This will also be reflected in the \$PSMDIN response: input 5 will report SeaTalk mode.

5: Generate VWR sentence from SeaTalk wind data. The default is to generate an MWV sentence.

6: Heading translation. Generate a true heading sentence (HDT) from a magnetic heading (HDM or HDG). The heading is corrected for magnetic variation if this field is available in the HDG or HDM sentence.

7: Velocity translation. Generate a log sentence (VHW) from a GPS speed sentence (VTG).

8: Reserved for future use.

9: Filter Block. Block sentences that are not in the Filter & Routing list. The default is to pass sentences that are not in the list.

10: Reverse heading. When enabled, a new HDT sentence is generated from an incoming HDT sentence with the heading reversed by 180 degrees. Use the Sentence Filter to route the original and new HDT sentences to different outputs.

11: Output channel information with STN sentences. When enabled, the multiplexer transmits an STN sentence before each individual sentence to indicate on which input this sentence was received.

12: Output channel information with TAG Blocks. . When enabled, the multiplexer transmits a TAG Block before each individual sentence to indicate on which input this sentence was received.

When a PSMDOP sentence without any parameters is sent, the multiplexer returns an OP sentence with a 32 bit hexadecimal number. Each bit represents an option where bit 0 is option 0, bit 1 is option 1 etc.

Format: \$PSMDOP*hh<CR><LF>

Response: \$PSMDOP,R,xxxxxxxx*hh<CR><LF>

\$PSMDOV – Overflow

In case of a queue overflow (blinking red LED on the multiplexer), an overflow sentence is output on the host interface, to indicate on which input queue the overflow occurred:

Format: \$PSMDOV,x*hh<CR><LF>

x: Binary field. The first four bits indicate on which input queue the overflow occurred.

\$PSMDRESET – Reset the multiplexer

This sentence resets the multiplexer and starts the bootloader. When a '1' is given as parameter, the factory settings of the multiplexer are restored.

Format: \$PSMDRESET,x*hh<CR><LF>

x: Optional parameter to indicate an action while resetting

1: restore the multiplexer to its factory settings

After a reset, the multiplexer outputs a LDR sentence and a VER sentence on the host interface.

\$PSMDSP – Set Speed

This sentence sets the baudrate of the NMEA inputs and outputs.

Format: \$PSMDSP,a,b,c,d,e,f,g[*hh]<CR><LF>

The following fields are defined for setting the various inputs and outputs:

- a: Sentence Status flag:
 - R = sentence is a status report of current settings
 - C = sentence is a command to change settings
- b: NMEA In 1
- c: NMEA In 2
- d: NMEA In 3
- e: NMEA In 4/Out 1
- f: NMEA Out 2
- g: RS-232 host port (ignored on multiplexers without RS-232 host port)

Valid field values are:

- 0 = 4800 Baud
- 1 = 9600 Baud
- 2 = 19200 Baud
- 3 = 38400 Baud
- 4 = 57600 Baud
- 5 = 115200 Baud (field e and f only)

Field 'e' is ignored when SeaTalk translation is enabled with the CF sentence.

\$PSMDUI – Set Unique Identifier

Sets the Unique Identifier (UI) of the multiplexer. This UI is sent as source parameter in TAG blocks sent by the multiplexer.

Format: \$PSMDUI,a,s*hh<CR><LF>

- a: Sentence Status flag:
 - R = sentence is a status report of current settings
 - C = sentence is a command to change settings
- s: Unique Identifier, 15 characters maximum. If this field exceeds the maximum character count, is not present or empty, the UI is reset to "MXnn" where "nn" are the last two digits of the serial number of the multiplexer.

\$PSMDVER – Get Version

This sentence retrieves version information from the multiplexer.

Format: \$PSMDVER

The multiplexer responds with the following version sentence:

\$PSMDVER,3.20.0,MiniPlex-2S,10025943,8040*hh<CR><LF>

- 3.20.0: firmware version number
- MiniPlex-2S: multiplexer name
- 10025943: serial number
- 8040: Multiplexer capabilities. This is a 4 digit, 16-bit field represented as a hexadecimal number. Each bit identifies a capability of the multiplexer. The following bits are defined:
 - 1-0: Host interface type, 0 = serial, 1 = USB, 2 = Ethernet, 3 = USB & WiFi
 - 2: Bluetooth module installed
 - 6: Firmware update supported
 - 15: 3rd generation multiplexer
- hh: checksum

\$PSMDWI – Wireless control

This sentence controls the wireless module on the multiplexer (WiFi or Bluetooth). This sentence always results in a response sentence from the multiplexer. This response reflects the response of the wireless module or the result of the operation.

Format: \$PSMDWI,x,a,b..*hh<CR><LF>

x: Sub-command. See below

a,b,..: Optional parameters required by a subcommand

Response: \$PSMDWI,message

The following sub-commands are defined:

0..6: Set the baud rate of communication port of the multiplexer that is connected to the wireless module. A single digit in the range of '0' to '6' sets the speed according to the table below:

- 0: 4800 Bd
- 1: 9600 Bd
- 2: 19200 Bd
- 3: 38400 Bd
- 4: 57600 Bd
- 5: 115200 Bd
- 6: 230400 Bd

This command is used to be able to talk to an un-initialized module at its default speeds of 9600 Bd (value '1') or when a firmware update requires a new speed setting.

This speed setting is temporary: after a power cycle the speed is reset to its normal operational value, determined by the firmware of the multiplexer.

A: Configure the WiFi module with the multiplexer default access point settings:

SSID: MiniPlex-2Wi:xx:yy
Channel: 1
IP address: 10.0.0.1
Network mask: 255.255.255.0
TCP port: 10110

xx:yy are the last two bytes of the MAC address of the WiFi module.

B: Configure the Bluetooth module with the multiplexer default settings

C: Set the wireless module to Command Mode. This enables sending of commands directly to the wireless module using the \$PSMDWI sentence. See section **Command Mode** for more details. Sending \$PSMDWI without any parameters exits Command Mode. When command mode is enabled, all NMEA data from In1..4 is blocked.

E: Erase the trusted (paired) devices list in the Bluetooth module.

M: Return the MAC address of the wireless module.

N: Set the network parameters of the WiFi connection:

\$PSMDWI,N,ip,mask,gw*hh<CR><LF>

ip: IP address, 0 for automatic assignment by a DHCP server
mask: network mask
gw: optional gateway address

\$PSMDWI,N,0 sets the multiplexer to DCHP in order to obtain all settings automatically.

The gateway address is only needed to obtain firmware updates of the WiFi module. When the ip field contains a '0', the IP settings will be obtained from a DHCP server and all other fields will be ignored. Fields may be omitted for parameters that need no change. For instance:

\$PSMDWI,N,,,192.168.1.1 only sets the gateway address.

T: Set the multiplexer to Terminal Mode. This opens a direct communication channel from the wired host interface to the wireless module. A terminal program can then be used to communicate directly with the wireless module. The multiplexer can be set to normal (NMEA) mode by a power cycle or by typing a ctrl-q character. See section **Terminal Mode** for more details

In Terminal Mode, the multiplexer does not respond to any proprietary NMEA commands, nor will it operate as a multiplexer.

U: Update the firmware in the WiFi module:

```
$PSMDWI,U,file,ip*hh<CR><LF>
```

file: File to load from the FTP server (optional)
ftp: IP address of the FTP server (optional)

The default file name is 'wifly-ap.img' and the default IP address is 195.8.209.192, which is the FTP server of ShipModul.

When none of the optional fields is specified, the multiplexer must be configured to connect to an existing access point with a connection to the Internet to be able to download a firmware image. This can be accomplished with the W and the N sub-commands.

The file and ftp fields are used by MPX-Config to be able to download a selected file from the FTP server built-in in MPX-Config.

V: Return the version number of the WiFi firmware. A \$PSMDWI,x.xx sentence is returned.

W: Set the WLAN parameters of the WiFi connection:

```
$PSMDWI,W,mode,ssid,phrase*hh<CR><LF>
```

mode: A = Access Point, I = Infrastructure
ssid: SSID of the WiFi connection
phrase: Optional pass phrase (only for Infrastructure mode)

When Access Point mode is set, the radio channel is set to 1 and the IP address/netmask are set to 10.0.0.1/255.255.255.0. They may be changed with the 'N' sub-command.

When Infrastructure mode is set, the radio channel is selected automatically and DHCP is enabled. The previously stored IP address/netmask are retained in case the multiplexer does not receive these from a DHCP server or access point.

Z: Configure the WiFi module for production testing

If any of the above commands fails, the wireless module may still be in Command Mode, indicated by a \$PSMDWC response instead of \$PSMDWI. To switch the multiplexer back to normal, a \$PSMDWI sentence must be issued without any parameters.

Command Mode

The sub commands listed above are used to change the most common settings of the wireless module by means of an NMEA sentence. The PSMDWI,A sentence for instance, sets over 25 parameters in the WiFi module automatically. In some cases, it is necessary to fine tune individual settings of the wireless module. Command Mode allows sending special commands to the module using an NMEA sentence. For instance, if you would need to change the MTU value of the WiFi connection, you can use the following sentences to do this:

```
$PSMDWI,C (enter command mode)
$PSMDWI,set ip mtu 600 (set the MTU value to 600)
$PSMDWI (exit command mode)
```

The second sentence sends the command 'set ip mtu 600' to the WiFi module.

The general format of a direct command sentence is:

```
$PSMDWI,command,[response],[time out][*hh]<CR><LF>
```

command: command to be sent to the wireless module.
[response]: optional expected response.
[time out]: optional time out value of 1..9 seconds. Standard time out is 1 second.

If an optional expected response is specified, the multiplexer returns either of two sentences:

```
$PSMDWC,OK (the module returned the expected response)
$PSMDWC,No Response (the expected response was not received)
```

If no expected response is specified, the multiplexer returns

```
$PSMDWC,message
```

where *message* is the response from the module.

The module-specific commands are not listed here because they fall outside the scope of this specification.

Note that the multiplexer responds with a \$PSMDWC sentence when it is in command mode. In normal mode, a \$PSMDWI response is given. A PSMDWI sentence without any parameters exits command mode. When this sentence is issued in normal mode, a \$PSMDWI,No response is returned.

Terminal Mode

Terminal Mode creates a direct connection between the wired and the wireless interface for testing and debugging purposes. All other inputs and outputs of the multiplexer are inactive.

A \$PSMDWI,T sentence enables Terminal Mode with the wireless module in Data mode. The blinking red LED indicates Terminal Mode.

At this point, a direct connection exists and no NMEA commands are recognised by the multiplexer. The connection is completely transparent and any (NMEA) data is passed in both ways. Three control codes are implemented to control Terminal Mode:

Ctrl-q: Exit Terminal Mode. The wireless module will be set to Data mode and the multiplexer returns to normal operation. The red LED is off.

Ctrl-c: Switch the wireless module to command mode, to control the configuration of the module through the wired interface.

Ctrl-d: Switch the wireless module to data mode.

Cycling the power of the multiplexer also exits Terminal Mode.

Channel Information

When a Channel Information option is enabled, the multiplexer will output a standard NMEA Multiple Data ID sentence or precede a sentence with a TAG block. Either of these contains the input number on which the following NMEA sentence was received.

STN – Multiple Data ID

When STN sentences are enabled (\$PSMDOP, option 11), the multiplexer transmits a \$MXSTN sentence before every NMEA sentence that is sent from the host interface.

Format: \$MXSTN,xx*hh<CR><LF>

xx: Input number, 00 to 05.

The Input Number indicates on which the following NMEA sentence was received. Input 00 represents internally generated sentences and input 05 represents conversion results.

TAG Blocks

When TAG Blocks are enabled (\$PSMDOP, option 12), the multiplexer adds a TAG block to every NMEA sentence that is sent from the host interface. This TAG block has one source parameter, containing the Unique Identifier (UI) of the multiplexer and the input the sentence was received on. This TAG block has the following format:

\s:UI-x*hh\

where UI is the Unique Identifier of the multiplexer and 'x' is a digit from 0 to 5, representing the input number. Input 0 represents internally generated sentences and input 5 represents conversion results. If no UI is specified with the PSMDUI sentence, "MXnn" is sent, where "nn" are the last two digits of the serial number of the multiplexer.

A heading sentence received on input 1 will be sent to the host as

\s:MX01-1*1E\ \$HEHDT,23.5*37<CR><LF>

Technical Specifications

MiniPlex-2S

Supply voltage:	8 – 35 V _{DC} , protected against reversed polarity.
Current consumption:	50 mA (100 mA max. with fully loaded talker ports)
Host interface:	RS-232, galvanically isolated
Inputs:	4 x NMEA 0183/RS-422, galvanically isolated. Input 4 can be set to SeaTalk mode
Input resistance:	>800 Ohm
Input current:	1.2mA @ 2V
Outputs:	2 x NMEA 0183/RS-422
Max output current:	20mA @ >2V
Queue size:	1024 characters
Filter list size:	50 sentence types
Priority list size:	50 sentence types
Speed NMEA In 1-3:	4800 - 57600 Baud
Speed NMEA In 4/Out 1:	4800 - 57600 Baud
Speed NMEA Out 2:	4800 - 115200 Baud
Indicators:	Overflow and Data
Dimensions:	138 x 72 x 33 mm
Housing:	Flame retardant ABS.

MiniPlex-2USB

Supply voltage:	8 – 35 V _{DC} , protected against reversed polarity.
Current consumption:	50 mA (100 mA max. with fully loaded talker ports)
Host interface:	USB, galvanically isolated
Inputs:	4 x NMEA 0183/RS-422, galvanically isolated. Input 4 can be set to SeaTalk mode
Input resistance:	>800 Ohm
Input current:	1.2mA @ 2V
Outputs:	2 x NMEA 0183/RS-422
Max output current:	20mA @ >2V
Queue size:	1024 characters
Filter list size:	50 sentence types
Priority list size:	50 sentence types
Speed NMEA In 1-3:	4800 - 57600 Baud
Speed NMEA In 4/Out 1:	4800 - 57600 Baud
Speed NMEA Out 2:	4800 - 115200 Baud
Indicators:	Overflow and Data
Dimensions:	138 x 72 x 33 mm
Housing:	Flame retardant ABS.

MiniPlex-2S/BT

Supply voltage:	8 – 35 V _{DC} , protected against reversed polarity.
Current consumption:	100 mA (150 mA max. with fully loaded talker ports)
Host interfaces:	RS-232, galvanically isolated Bluetooth V2.0, Class 1 (+6dBm), SPP
Bluetooth range:	250 metres typical in free space
Inputs:	4 x NMEA 0183/RS-422, galvanically isolated. Input 4 can be set to SeaTalk mode
Input resistance:	>800 Ohm
Input current:	1.2mA @ 2V
Outputs:	2 x NMEA 0183/RS-422
Max output current:	20mA @ >2V
Queue size:	1024 characters
Filter list size:	50 sentence types
Priority list size:	50 sentence types
Speed NMEA In 1-3:	4800 - 57600 Baud
Speed NMEA In 4/Out 1:	4800 - 57600 Baud
Speed NMEA Out 2:	4800 - 115200 Baud
Indicators:	Overflow and Data
Dimensions:	138 x 72 x 33 mm
Housing:	Flame retardant ABS.

MiniPlex-2USB/BT

Supply voltage:	8 – 35 V _{DC} , protected against reversed polarity.
Current consumption:	100 mA (150 mA max. with fully loaded talker ports)
Host interfaces:	USB, galvanically isolated Bluetooth V2.0, Class 1 (+6dBm), SPP
Bluetooth range:	250 metres typical in free space
Inputs:	4 x NMEA 0183/RS-422, galvanically isolated. Input 4 can be set to SeaTalk mode
Input resistance:	>800 Ohm
Input current:	1.2mA @ 2V
Outputs:	2 x NMEA 0183/RS-422
Max output current:	20mA @ >2V
Queue size:	1024 characters
Filter list size:	50 sentence types
Priority list size:	50 sentence types
Speed NMEA In 1-3:	4800 - 57600 Baud
Speed NMEA In 4/Out 1:	4800 - 57600 Baud
Speed NMEA Out 2:	4800 - 115200 Baud
Indicators:	Overflow and Data
Dimensions:	138 x 72 x 33 mm
Housing:	Flame retardant ABS.

MiniPlex-2E

Supply voltage:	8 – 35 V _{DC} , protected against reversed polarity.
Current consumption:	100 mA (150 mA max. with fully loaded talker ports)
Host interface:	10BASE-T/100BASE-TX Ethernet
Supported protocols:	TCP/IP and UDP, port 10110 for NMEA communication TCP/IP, port 10110 for firmware updates TCP/IP and UDP, port 30718 for network configuration ARP, ICMP and DHCP for network management
Inputs:	4 x NMEA 0183/RS-422, galvanically isolated. Input 4 can be set to SeaTalk mode
Input resistance:	>800 Ohm
Input current:	1.2mA @ 2V
Outputs:	2 x NMEA 0183/RS-422
Max output current:	20mA @ >2V
Queue size:	1024 characters
Filter list size:	50 sentence types
Priority list size:	50 sentence types
Speed NMEA In 1-3:	4800 - 57600 Baud
Speed NMEA In 4/Out 1:	4800 - 57600 Baud
Speed NMEA Out 2:	4800 - 115200 Baud
Indicators:	Overflow and Data
Dimensions:	138 x 72 x 33 mm
Housing:	Flame retardant ABS.

MiniPlex-2Wi

Supply voltage:	8 – 35 V _{DC} , protected against reversed polarity.
Current consumption:	65 mA (115 mA max. with fully loaded talker ports)
Host interfaces:	USB, galvanically isolated WiFi 802.11b+g, +10dBm
Supported protocols:	TCP/IP and UDP, port 10110 for NMEA communication ARP, ICMP and DHCP for network management
Inputs:	4 x NMEA 0183/RS-422, galvanically isolated. Input 4 can be set to SeaTalk mode
Input resistance:	>800 Ohm
Input current:	1.2mA @ 2V
Outputs:	2 x NMEA 0183/RS-422
Max output current:	20mA @ >2V
Queue size:	1024 characters
Filter list size:	50 sentence types
Priority list size:	50 sentence types
Speed NMEA In 1-3:	4800 - 57600 Baud
Speed NMEA In 4/Out 1:	4800 - 57600 Baud
Speed NMEA Out 2:	4800 - 115200 Baud
Indicators:	Overflow and Data
Dimensions:	138 x 72 x 33 mm
Housing:	Flame retardant ABS.

ShipModul B.V.
Zwedenlaan 3
9403 DD Assen
The Netherlands

web: www.shipmodul.com
e-mail: support@shipmodul.com